




MECHANICAL VACUUM LIFTERS

SERIES 250, 600, 1000

OWNER'S MANUAL

Get The Aardwolf AAdvantage

EN 



Welcome onboard!

Thank you so much for your selection of Aardwolf Vacuum Lifter! You and your new Aardwolf Mechanical Vacuum Lifter are now companions. Please read this manual to understand your companion.

This Manual of Mechanical Vacuum Lifter is designed to provide the important information regarding the purposes, uses and maintenances of all mechanical vacuum lifters. It is compulsory for the operator to carefully read over the manual before operating the lifter and keep it available for reference at any time in the workplace.

In the manual, you will find operating instructions, safety precautions, product specifications, drawing and spare parts list as well as maintenance and inspections.

Aardwolf Industries LLC



1. Description of lifter1

2. Specifications1

 2.1 Specifications1

 2.2 Markings7

3. Operating instructions8

 3.1 Before operating the lifter8

 • Attaching the lifter to hoisting equipment8

 • Safety instruction9

 • Dos and Don'ts for operator's safety10

 • How mechanical vacuum lifter work?13

 • Basic Operating Procedure13

 • Technical description14

 • How safe is vacuum handling?15

 • Assembly of lifter18

 3.2 Instructions for use19

 • Erroneous Use21

 • Storage of lifter21

 • Overhang Table21

 • Load Overhang Calculation24

 • Inspections and maintenance guides25



• Inspections schedule.....	26
• Testing schedule	26
• Load test	26
• Vacuum test	27
• Vacuum pad maintenance	27
• Checklist of maintenance items	29
• Trouble shooting Procedures for AARDWOLF Mechanical Vacuum Lifters	30
• Replacing Vacuum Pads and Sealing Rings	34
• Instructions of disassembling and inspection of diaphragm	35
• Aardwolf Vacuum Leakage Detector VLD - 02	44
• PS - 150 Parking Stands	47
4. Inspection report	48
5. Spare part list	54
6. Warranty	75
6.1 Warranty	75
6.2 Disclaimer	76

1. DESCRIPTION OF LIFTER

The Aardwolf Mechanical Vacuum Lifters are designed to horizontally handle non-porous sheet and plate materials such as diamond sawn or polished granite, polished engineered stone, all types of metals, plastics and fiberglass.

By means of an automatic self-cycling valve, the vacuum grip and release cycle is assuredly safe and secure.

2. SPECIFICATIONS

Mechanical Vacuum Lifter AMVL250-2

PRODUCT CODE	AMVL250-2
VACUUM PAD FRAME CONFIGURATION	TWO VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 300MM (11 4/5") OVERALL 365MM (1' 2 3/8")
LOAD CAPACITY	250 KGS (551 LBS)
NET WEIGHT	46 KGS (101 LBS)

Mechanical Vacuum Lifter AMVL250-4 (In Line)

PRODUCT CODE	AMVL250-4 IN LINE
VACUUM PAD FRAME CONFIGURATION	FOUR VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 190MM (7 ½")
LOAD CAPACITY	250 KGS (551 LBS)
NET WEIGHT	47 KGS (103.6 LBS)



2. SPECIFICATIONS

Mechanical Vacuum Lifter AMVL250-4

PRODUCT CODE	AMVL250-4
VACUUM PAD FRAME CONFIGURATION	FOUR VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 190MM (7 ½")
LOAD CAPACITY	250 KGS (551 LBS)
NET WEIGHT	47 KGS (103.6 LBS)

Mechanical Vacuum Lifter AMVL250-8

PRODUCT CODE	AMVL250-8
VACUUM PAD FRAME CONFIGURATION	EIGHT VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 120MM (4 2/3")
LOAD CAPACITY	250 KGS (551 LBS)
NET WEIGHT	63 KGS (139 LBS)

For Mechanical Vacuum Lifter of Series 600

Mono Mechanical Vacuum Lifter AMMVL650

PRODUCT CODE	AMMVL650
VACUUM PAD FRAME CONFIGURATION	ONE VACUUM PAD
PADS DIAMETER	SEAL TO SEAL 450MM (1' 5 2/3")
LOAD CAPACITY	650 KGS (1433 LBS)



2. SPECIFICATIONS

Mechanical Vacuum Lifter AMVL600-2

PRODUCT CODE	AMVL600-2
VACUUM PAD FRAME CONFIGURATION	TWO VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 300MM (11 4/5") OVERALL 365MM (1' 2 3/8")
LOAD CAPACITY	600 KGS (1323 LBS)
NET WEIGHT	62 KGS (136.7 LBS)

Mechanical Vacuum Lifter AMVL600-4 (In Line)

PRODUCT CODE	AMVL600-4 IN LINE
VACUUM PAD FRAME CONFIGURATION	FOUR VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 300MM (11 2/5")
LOAD CAPACITY	600 KGS (1323 LBS)
NET WEIGHT	128 KGS (282 LBS)

Mechanical Vacuum Lifter AMVL600-4

PRODUCT CODE	AMVL600-4
VACUUM PAD FRAME CONFIGURATION	FOUR VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 225 MM (8 5/6")
LOAD CAPACITY	600 KGS (1323 LBS)

128 KGS (282 LBS)



2. SPECIFICATIONS

Mechanical Vacuum Lifter AMVL600-8

PRODUCT CODE	AMVL600-8
VACUUM PAD FRAME CONFIGURATION	EIGHT VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 190MM (7 1/2")
LOAD CAPACITY	600 KGS (1323 LBS)
NET WEIGHT	47 KGS (163 LBS)

For Mechanical Vacuum Lifter of Series 1000

Mono Mechanical Vacuum Lifter AMMVL1000

PRODUCT CODE	AMMVL1000
VACUUM PAD FRAME CONFIGURATION	ONE VACUUM PAD
PADS DIAMETER	SEAL TO SEAL 530MM (1' 8 5/6")
LOAD CAPACITY	1000 KGS (2205 LBS)
NET WEIGHT	55 KGS (121.3 LBS)

Mechanical Vacuum Lifter AMVL1000-2

PRODUCT CODE	AMVL1000-2
VACUUM PAD FRAME CONFIGURATION	TWO VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 450MM (1' 5 2/3")
LOAD CAPACITY	1000 KGS (2205 LBS)
NET WEIGHT	245KG (529 LBS)



2. SPECIFICATIONS

Mechanical Vacuum Lifter AMVL1000-4

PRODUCT CODE	AMVL1000-4
VACUUM PAD FRAME CONFIGURATION	FOUR VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 300MM (11 4/5")
LOAD CAPACITY	1000 KGS (2205 LBS)
NET WEIGHT	225 KGS (496 LBS)

Mechanical Vacuum Lifter AMVL1000-8

PRODUCT CODE	AMVL1000-8
VACUUM PAD FRAME CONFIGURATION	EIGHT VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 300MM (11 4/5")
LOAD CAPACITY	1000 KGS (2205 LBS)
NET WEIGHT	318 KGS (701 LBS)


Mechanical Vacuum Lifter AMVL1000-10

PRODUCT CODE	AMVL1000-10
VACUUM PAD FRAME CONFIGURATION	TEN VACUUM PADS
PADS DIAMETER	SEAL TO SEAL 190MM (7 ½")
LOAD CAPACITY	1000 KGS 92205 LBS)
NET WEIGHT	340 KGS (750 LBS)



2. SPECIFICATIONS

2.2 MARKINGS



W.L.L. 
75 Kgs

W.L.L. 
150 Kgs

W.L.L. 
270 Kgs

W.L.L. 
600 Kgs

W.L.L. 
650 Kgs

W.L.L. 
1100 Kgs

W.L.L. 
2200 Kgs



3. OPERATING INSTRUCTIONS

3.1 BEFORE OPERATING THE LIFTER

"Check the following points before operating the lifter"

Ensure that the following points are checked before operating the lifter:
1. The lifter is in the correct position and the load is secure.

2. The operator is wearing the correct safety gear and is trained to operate the lifter.

3. The area around the lifter is clear of obstacles and personnel.

4. The weather conditions are suitable for operating the lifter.

5. The operator has read and understood the operating instructions.

6. The lifter is in good working order and has been inspected by a competent person.

7. The operator is aware of the maximum load capacity of the lifter.

8. The operator is aware of the potential hazards of the lifter.

9. The operator is aware of the correct way to use the lifter.

10. The operator is aware of the correct way to store the lifter.

11. The operator is aware of the correct way to maintain the lifter.

12. The operator is aware of the correct way to transport the lifter.

13. The operator is aware of the correct way to dispose of the lifter.

14. The operator is aware of the correct way to use the lifter in different environments.

15. The operator is aware of the correct way to use the lifter in different weather conditions.

3. OPERATING INSTRUCTIONS

ËÜ^æá@Á•c˘&ā}ÁæáÁ^ıçā^Áæ˘æÈ

ÈT æ^Á\|cə ÁəÁ\|ʼ|æə *Áʼ\|[]^|æ^Áə äəÁ äö@Á\|ʼ|æə *Á\|&ʼ|ʼ•
ə äÁ æ^Áäc *Á\|æcÁ•Èc Á\|Ác Á\|əʼ•cə äə *ÁəÁ@Ác •È\|ʼ•Ác ä
|ʼ^|æə\|•Á\| äcÁ\|Á\|•È@ÈQ\|Áäc *Á^cÁ•È

CAUTION

If the unit has been exposed to a cold environment (below 35°F) the mechanical valve mechanism, sealing ring and rolling diaphragm may be cold and stiff. To prevent damage to the internal rolling diaphragm and to ensure proper sealing of the rubber sealing ring, allow the unit to remain in a heated area (above 35°F) for a few hours prior to operation.

Place the lifter with the seals off the ground to allow the sealing rings to relax from their compressed condition on the shipping skid. Do not hang lifter from shackle for long periods of time with no load.

When starting up a new and/or cold unit, raise and lower the piston several times at slow speed to the flex the rolling diaphragm before making a lift.

" Ûæ^c Â Á • d ~ & cā }

EÜ\{ ^\{ à\!A@A\!|\!^!Aa*Á\[, \!a*^Aa@a*~^•Aa^A@Á•\[\]•aa
 [\!^!a\!EÜ^Á\!^!A^aaAa\!a\!•a@a@A\!•d\!&\!}•AaÁaæc
 ,æ\!a*•A\}aa^aA@Aa\!a\!^!\!Á•a*Á\!^!aæ~\!Aa^!E

ÈGÁ[~ Á[Á[Á[] á! • ca á Á Ç! ~ ca * Á Á Á á ~ á[Á] ca á Á á, [| Á á • d á • ŠŠÓÁ! Á • á ca & Á Á! | Á Á • á * Á Á Á á! È

ES^ ^] A@Aae!A A A [[aA} aa } Aa aAae!~ A ~ A @ A ae c } ae & A & @ a ~ | ^
^•aa|a @aA~ A@A ae ~ aeC |^E

ÈS^^] Á@Áac^/Á^æ Áq áÁ!^Êq áÁ^^Á[{ Áààà ËÖ|^æ Á] Á[^ÁÁac
æ&& { ^|æ^Á] Á^!-æÁÁq áÁ•]^&æ| Á] Á@Á^ àà^!Á^•ó|ç^!Á@æÁ Áãã|
+[{ Á@Á] È



[illegible]

ÈÜ) &A& ^\^| È&@&A&@&æ~{ Å[••Å^)]| Å& aÅ æ) æ* Å&ç&Å& æ&•c
 •, æ&Å Å æÅ^| Å&@Å|] Å& aÅ @ Å| Å& Å| Å&q ÈÅ@Å|, Å&æÅ^|
 æ a&æ Å| Å| Å&æ Å&@Å|] Å& a&@ Å&O&æ& Å& Å& Å| Å& d Å| @ Å&æ
 [|, Å| Å| Å| ÈÜ^|] æ Å&æ Å& Å| @ Å& Å& Å&••æ È

EU) & ^ Á ç ^ ! ^ Á [] o ð ð @ & Á ç æ ~ { Á æ * ^ Ð Ð Á æ ^ Á ~ ! ^ Á @ Á æ
 ~ } ð c ! " " c á ! Á ç æ ! • Á ç á á @ Á ç æ ã Á á Á ç æ } Á & Á æ ! Á ç á ! É

[illegible][illegible]

ÉÁá^Á@!Á a~}&ā}•Á^Áà•^!ç^âË&@&Á[~!Á[~à!^Á@!ā*Á~ā^Á!
&}æ&Œæâ,[!Áâ~dâ•ËŒŒ!Á!çâÈ

“ Ö | • Á æ å Ä Ö | } q Á | Á | ^ | æ | q Á æ ^ ĉ

[illegible]

3. OPERATING INSTRUCTIONS

[illegible]

EÖ[Á[[Á] ^!æ^Áæ^!Á ã@~Á•] ^&ā} Ág áÁ^•ā* Á!ā!Á Áæ@ Áæ

EÜÄ [[1 4 9 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212 213 214 215 216 217 218 219 220 221 222 223 224 225 226 227 228 229 230 231 232 233 234 235 236 237 238 239 240 241 242 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262 263 264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295 296 297 298 299 300 301 302 303 304 305 306 307 308 309 310 311 312 313 314 315 316 317 318 319 320 321 322 323 324 325 326 327 328 329 330 331 332 333 334 335 336 337 338 339 340 341 342 343 344 345 346 347 348 349 350 351 352 353 354 355 356 357 358 359 360 361 362 363 364 365 366 367 368 369 370 371 372 373 374 375 376 377 378 379 380 381 382 383 384 385 386 387 388 389 390 391 392 393 394 395 396 397 398 399 400 401 402 403 404 405 406 407 408 409 410 411 412 413 414 415 416 417 418 419 420 421 422 423 424 425 426 427 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462 463 464 465 466 467 468 469 470 471 472 473 474 475 476 477 478 479 480 481 482 483 484 485 486 487 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504 505 506 507 508 509 510 511 512 513 514 515 516 517 518 519 520 521 522 523 524 525 526 527 528 529 530 531 532 533 534 535 536 537 538 539 540 541 542 543 544 545 546 547 548 549 550 551 552 553 554 555 556 557 558 559 560 561 562 563 564 565 566 567 568 569 570 571 572 573 574 575 576 577 578 579 580 581 582 583 584 585 586 587 588 589 590 591 592 593 594 595 596 597 598 599 600 601 602 603 604 605 606 607 608 609 610 611 612 613 614 615 616 617 618 619 620 621 622 623 624 625 626 627 628 629 630 631 632 633 634 635 636 637 638 639 640 641 642 643 644 645 646 647 648 649 650 651 652 653 654 655 656 657 658 659 660 661 662 663 664 665 666 667 668 669 670 671 672 673 674 675 676 677 678 679 680 681 682 683 684 685 686 687 688 689 690 691 692 693 694 695 696 697 698 699 700 701 702 703 704 705 706 707 708 709 710 711 712 713 714 715 716 717 718 719 720 721 722 723 724 725 726 727 728 729 730 731 732 733 734 735 736 737 738 739 740 741 742 743 744 745 746 747 748 749 750 751 752 753 754 755 756 757 758 759 760 761 762 763 764 765 766 767 768 769 770 771 772 773 774 775 776 777 778 779 780 781 782 783 784 785 786 787 788 789 790 791 792 793 794 795 796 797 798 799 800 801 802 803 804 805 806 807 808 809 810 811 812 813 814 815 816 817 818 819 820 821 822 823 824 825 826 827 828 829 830 831 832 833 834 835 836 837 838 839 840 841 842 843 844 845 846 847 848 849 850 851 852 853 854 855 856 857 858 859 860 861 862 863 864 865 866 867 868 869 870 871 872 873 874 875 876 877 878 879 880 881 882 883 884 885 886 887 888 889 890 891 892 893 894 895 896 897 898 899 900 901 902 903 904 905 906 907 908 909 910 911 912 913 914 915 916 917 918 919 920 921 922 923 924 925 926 927 928 929 930 931 932 933 934 935 936 937 938 939 940 941 942 943 944 945 946 947 948 949 950 951 952 953 954 955 956 957 958 959 960 961 962 963 964 965 966 967 968 969 970 971 972 973 974 975 976 977 978 979 980 981 982 983 984 985 986 987 988 989 990 991 992 993 994 995 996 997 998 999 1000 1001 1002 1003 1004 1005 1006 1007 1008 1009 1010 1011 1012 1013 1014 1015 1016 1017 1018 1019 1020 1021 1022 1023 1024 1025 1026 1027 1028 1029 1030 1031 1032 1033 1034 1035 1036 1037 1038

EÖ[Á[á•^áæ { Áæ * Á^çá Á áöá Áu á Á!á!Áæ Á} áÁ^ç!) ^áÁ
]!] ^!Á] ^!æ * & } áá } È

Ö [Á [á • ^ ã æ | Á & æ æ ã Á | Á æ ^ Á æ | ā * • Á æ ^ Á ã • ā * È

EÖ[Á[Á•^Á@Á~`a{ ^}oÁ@Áæ^cÁ^çÁ•Áæ^Á[Á^!^&q^Á•æ||^áÁ)á
 ,[||a*Á~Á)q^È

ÈT æ^ Á~\^Á@æÁ~]][[ç^ *Ád~&c\^Áq áÁ\ æEæ&@^ *Á^ç&•ÁE Ææ æ^ È
 &@æ Ææ áÁQ \Dæ^Áæ æÁÁ Á~]][[ó@Á^ Áæ @Á^ Á@Áæ\Áæ áÁ\ æE

ËÓÁ^|\^|Á^|àààà@Á^à@|Á@Á^|Á|{Á|à^Á|ÁqãàààààÁ@}
8a8^|aà*Á@ÁààààÁ^àààààÁ^Á@Á^•c^|Ë

ËW^Áã^Á}[^Á}Á[]Ë[[]~•Á{[[c@Áæ•È

ËÖ̈Ä̈Ė̈æ̈Á[æ̈&̈æ̈ã̈À̈ Á̈Ě̈Ã̈Á[|Á̈æ̈@̈F̈€̈Á̈Ď̈Á̈|̈ç̈æ̈} Á̈æ̈[ç̈^̈Á̈^̈æ̈|̈ç̈^̈|È̈

[illegible]

ÈÖ! Á! á! ^! Á! ^! Á! }! Á! á! á! á! @! Á! á! |! Á! ^! ^! á! á! á! á! |! Á! &! á! á! ^! |! á! ^! á! ^!
 |! á! ^! á! ^! Á! ^! á! @! á! Á! |! |! ^! á! @! Á! á! á! á! ^! á! á! á! ^! *! Á! á! á! á! É

EÖI [Á | Á•^Áæ | Á } Á æ • ÁæÁæÁæÁæÁæÁæ { { ^ } á^á^ } * Áæ Á Á æ Á Á Áæ
 | æ Áæ | æ Á Áæ } • • EÖI } • | Á æ Á Á Á | Áæ * Áæ Á Á Áæ } Áæ Á Á Á Á Áæ Á æ • Áæ

ÈÖ|Á|~~qāā~~ [!^Á~~qāā~~Á}^Á|!|Áā&^~~āāāā~~^~~ĖĖ~~@^•~~āā~~^~~ĖĖ~~|~~āā~~^Á@
 [|~~āā~~Á|,|Á{^~~āāāā~~^~~āā~~Á|~~āā~~@^•~~āā~~Á~~āā~~@~~āā~~*^Á|^Á|ā|Á~~āā~~*È

EW^A@A~ q { ^} oA } | A | A@A\ • Aœ oQ | a^aA^ A@A œ ~ œc | A | EÖ
 ~ } q c } a^aA^ • Aœ A ~ oA [] | q A œ c A aA@ œ c A aA^ A aA@Aœ }
 & [{ ^ | & A œ œ ^ E

EW^AœA | A } | A | A@ | a [] œ A œ A * A aA^A A A c^ | @ œ A œ } [| œ } EÖ A [c
 ~ • A œ A | A A œ A | œ • A c^ | A [| • E

EW^A@Aœ a | ^ œ • A A [• œ } A@AœA | A aA~ œ^A@A | œ E

EÖ A [oA ~ • oA | A ~ | A@A | œ A œ A [~ | Aœ a • A } A@A | œ E

EÖ&^ | Aœ A aA^ &^ | Aœ A | œ • A { [| oQ E

EÖ [œ A } œ oA A | œ • A œ A a • d ~ & } • E

EY @ | Aœ b • c * A [• A { • A aA œ A^ A A œ ~ { A a • A^A A A a • A a
 \ a • EÖ A [oA q & A@A œ ~ { A a • E

EY @ | A } | q * A@A^cœ • A } q A@A œ A œ A œ A^ ~ | A@A | a A A [] | ^
 ^ c^ c a EÖ œ A ~ A ~ A@Aœ a | q * A œ q ~ oA œ * A@A ~ q { ^} oA | Aœ A [{
 oA A [~] a Aœ | œ A ~ A œ ~ } oA [c^ { ^} oA aA^ A [~ | ^ | Aœ A œ A œ A œ & E

EÖ A [oA oA | œ • Aœ @ | Aœ A A^ & • œ E

EÜ | ^ c^ } oA A ~ • œ A • A [{ A œ q * A [A [• A A A@A | ^ œ * A œ Aœ A A@
 ^ ~ q { ^} oA A a * A • A a EÖ A^ & • œ E q | A@A ~ q { ^} oA | Aœ } A { ^ a
 œ | A aA^ A c^ | ^ a | a A œ œ A [{ A@A [| A q * A œ œ

EÖ A [oA œ A | œ A [| ^ Aœ A | oA [{ A@ | a [] œ A^ c^ | Aœ A c& • œ ^ | A^ c
 [| A q A | œ E

EÖ A [oA • A œ A | A | œ • A • Aœ A A A A Aœ a A œ œ A | A q * | A œ Aœ • E

EÖ œ • A œ A | œ A A@A | œ EÖ A [oA | œ A | ^ | A^ oA | Aœ a • A } a | A@A | œ E
 S^ A [~ | Aœ A a A | a A œ œ A [{ Aœ A | A | œ A A c^ } oA Aœ Aœ } œ
 | ^ | œ E

EÖ A [oA^ A | œ • A ~ • } ^ a^ A | A } ^ & • œ q A | * A | a a • A ~ & A A | a *
 & ~ A | A } & A^ œ • A | A oA [| A q] œ E

3. OPERATING INSTRUCTIONS

- Do not stand under suspended loads or lift loads over people.
- Be sure to inform those near you that a lifting operation is about to begin.
- Check all fasteners for tightness. Vibration during shipping can loosen screws and bolts. All position locking knobs or wing nuts are tight and pads and/or cross-arms are correctly positioned.
- The shackle/master link is not twisted when hanging the unit on the crane hook.
- During operation always wear the individual protection clothing and/or devices indicated in the operating instructions supplied by the manufacturer and those provided by the applicable legislation concerning safety at the workplace.

- How mechanical vacuum lifter work?

Upward/downward movement controls vacuum pickup and release.

Simply on/off cycle is quick and reliable.

Raising the hoist hook and piston creates a vacuum in chamber formed by piston bottom, cylinder walls and load surface.

Flexible vacuum sealing ring around bottom flange seals out outside air. Vacuum secures powerful “bond” between lifter and load which now can be lifted. When the load and lifter are lowered, piston descends in cylinder. At lowest point the piston valve opens and lifter can be released from load, ready for next pick-up.

- Basic Operating Procedure

1. Lower lifter onto load until the shackle/master link is slack.
2. Raise hoist to lift shackle/master link and internal piston to create vacuum.
3. Vacuum pad of lifter attaches and lifts the load.
4. Transport the load to the expected location.
5. Lower the hoist until shackle/master link is slack again.
6. Internal valve now makes a cycle route to release the vacuum and detach the load.
7. Lifter may now be raised slowly until the load is released.



"V&@æÁ^•&äü }


V@Äæ~{ Á^}^!æ!|Ä-Ä@Äæä, [|Äæ!Ä|}•ä@Ä-ÄÄ^Ä [çä*Ääü}Ä
, æ@Äæ|•^ä&|ä ä^!ÄÄ äà^!Ä [|ä*Äæ @æ{ Ä!{ •Äææä @Ä^æÄ
à^ç ^^}Ääü}Ä ä&|ä ä^!ÄÜä &Ä@Äç*!æ Ä-ÄÄÄ^æ[^•Ä [ö^}^} äÄ}Ä
{ ^æüüüü ^æÄ|}ææ[^•Ä [ü|•^Ä-æ) &Ä Ä|]^!æ}É

Y @}Ä@Ä|æÄÄ|{]|^|^Ä^Ä|, }Ä äÄ@Ä æ| |Ä æç!Ää \Ä Äæ Ä
•|æ^}^äÄ@Äæ Ä|^}•Ä@Ääü}Äæç^Ä|^æä*Ä@Äæ~{ ÄV@Äæ!Ä@}Ä
&Ä Ä^Äæ^äÄæ^Ä|Äæ^Ä|Ä@Ä^çüæ~]É


V@Ä|^!æ}Ä-Ä|ä Ä äÄ|^æ^Ä/Ä/çæç^|^~•ÄÜä &Ä@Äæç^Äæ Ä|^Ä
&Ä^Ä @}Ä@Ä æ|^æ çç!Ää \ÄÄ|{]|^|^Ä|æ Äæ}[ö^Ä æ^äÄ Ä@Ä
%æ|^æ^Ä|•äü}Ä ç^Ä|ææÄÄ^*Ä@ÄäÉ

P[| \Ä~•|^}ä^äÄæ!Ä|æ^äÄ}Ä|æäü}Ä^•&^}äÄ Ä|, ^•ü|•äü}Ä
]äü}Äæç^Ä|•^•Ä^ä @Ä Äæ!Ä|{]|^••^•Äæ~{ Ä^æÄ^ç ^^}Ä|ü{ Ä
-æ*^Ä äÄ|æÄ-æÉ


3. OPERATING INSTRUCTIONS



SECTION OF MECHANICAL
VACUUM LIFTER SERIES
250



SECTION OF MECHANICAL
VACUUM LIFTER SERIES
600



SECTION OF MECHANICAL
VACUUM LIFTER SERIES
1000




3. OPERATING INSTRUCTIONS

[illegible]

“P[. Áæ^Á& Áæ& ~ { Áæ& á|ā * Ñ

Xæ~{ Á•^Á@Á} æð * Áæ [•] @!æÁ|^•~|^Áæ Áæ[~|&Á-Á[, ^!Áæ áÁ
o@Á|^!*Á[~|&Á Áæ æð Áæ^Áæ áÁ|^æ|Æ



V@&æ~{ Å^ç ^^} Å&æ~{ Å æ&æ æ Å@Å~!-æ Å Å~ ææ|Å æ& Å @& Å
æ Å@|å Å Å|æ Å Å~ æ àà!Å^æ&{]|!••å& Å^ç ^^} Å æ&æ æ Å| æ& Å æ Å
^ç^!Å æ& Å @|å& Å| æ& Å| Å~••Å@&æ~{ Å Å^å & å Å~ Å æ æ æ Å Å Å Å Å
@Å æ Å^ç ^^} Å@Å æ&æ æ Å@Å| æ& Å~!-æ È

[illegible]



UÙÜŒ/ŒPÁJØ
T ÒÔPŒPÔŒŠKŒWWT
ŠŒVÒÜÀÒÜÒÜÁ €



3. OPERATING INSTRUCTIONS



OPERATION OF MECHANICAL VACUUM LIFTER SERIES 600



OPERATION OF MECHANICAL VACUUM LIFTER SERIES 1000




3. OPERATING INSTRUCTIONS

V@Á!^æ•ó[~!&^Á-Á ā @æ•Á!Áæ~!^•Á ā@çæ~{ Á@æ ā|ā *Á~ā { ^} ó
 [&&!•Á ā@Á ā æ] |æææ } Åæ āÁ@ { æ Áæ~!^É@çæ~{ Áæç!Á Áæ } ^&æā āāÁ
 |āç *Á[|Áæ āÁ @~|āÁ[óÁ^Á^æ āÁæ Áæ^ } ^|æ] ~! [•^Á@æ ā|Á! Á^ ÁÁÁÁÁÁÁÁ
 [] ^!æ āÁ^ Á } dæ āÁææ |Á } Åæ ^ Åæ āÁæ|Á ææ É@ç! Á^ææ^ ā
 !^&[{ { ^} āææ] •Á! Áæ^Áæ~{ Á@æ ā|ā *Éæ, æ •Á^~!Á! Á@Áæ~{ Áæç!Á
 ā •d~&ç } Á æ~æÁæ āÁ[{]! Á ā@Á|Á@Áæ •É~!^• Åæ āÁ^~|ææ } •ÁÁÁÁÁÁÁÁ
 æ] |ææ|Á! Á[~!Á[~} d^É

P[, ^ç^!É @} Á] ^!æ āÁæ Á^&[{ { ^} āāÁ^ Á@Á~] |ā!•Á Áæ~{ Áæç!•É
 @•^Á^•ç! Á@æ^Á^ } Á! [ç^} Á! Á^Áçd^ { ^!ÁæÁ! Á!] ^!æ! •Åæ āÁ[[Á
] ^!•[] } ^!Á Á [Á] ^Á ^ā•Á! Á^ó[•^Á! Á@Á! æÁæ āÁ [Á@æ ā •Áæ^Á^~ āāÁ
 ç Áææ@æ āÁ^ææ@ç@Á! æÉ

~ Ç•^! à!Á-Áæç!

V) à[çæ āÁæ^ { à! Á@Áæç! Áæ^āÁ } Á@Á! || , ā *Á^&@ ææÁ!æ ā *K



3. OPERATING INSTRUCTIONS

NOTE

FÈV@Á} áÁ•^|Á @~|á&@&|Á|Á} æ^Á æ°Áæ^áÁ} Á@Á} æ^Á æ°Áæ^á á
^}•~|^Á@Á| Á{ •Á@Á^} Áæ æ^áÁ|Á|•Á~|á*Á@{ ^} ðÁÁç^} c
[ÁæÁ|Áæ æ^Á Á{ Á{ •É{ ^áæ~|Á{ }{ Á@Áæðæ~ç|Á|Á^|Á|
, æ@Á Áæ•Áá &Á@ÁæÁ Á[[áÁ^&á•É

GÈV@Á•^| á|Á Áæ^|Á @~|áÁ^Áæ|ááÁ~Á^Á}|^Á{| ^} Á^|•|} Á @
@Á^} Áæ áæÁ æ@ÁÁæ^•É

HÈCá, [|Áá~•á•ÁSSÖÁ æ|æ çÁ|^Á| çÁç^|Á~Áæ|Á~Á^Á|
á&||^Á@Á•^| á|Á Áæ|Á&{| ^} Á^|•|} Á|Á^|æ^| ^} Á~
|}| É|ááæ|Á{ •Á|Áæ|^ÁÁ{| }{ æÁÁ æ~æç^|ÁçÁ æ~æÉ

CAUTION

If the unit has been exposed to a cold environment (below 35°F) the mechanical valve mechanism, sealing ring and the rolling diaphragm may be cold and stiff. To prevent damage to the internal rolling diaphragm and to ensure proper sealing of the rubber sealing ring, allow the unit to remain in a heated area (above 35°F) for a few hours prior to operation.

Place the lifter with the seals off the ground to allow the sealing rings to relax from their compressed condition on the shipping skid. Do not hang lifter from shackle for long periods of time with no load.

When starting up a new and/or cold unit, raise and lower the piston several times at slow speed to the flex the rolling diaphragm before making a lift.

3.2 INSTRUCTIONS FOR USE

FÈT æ^Á~|^Á@Á@Áæ~{ Áæ^|ÁÁ{| } æá|Á æ@ÁÁ~á{ ^} Áæ ææÉ
GÈT æ^Á~|^Á@Á@Á|^|æá*Áææ~|^ÁÁ|}|}|æÁ æ^ç^|á*
•|æÁæ áÁ~æá|Á} çá|}{ ^} æÁ{| áæ}•É



3. OPERATING INSTRUCTIONS

HÈY @ÀÁãç * È@Àçæ~ { Áæ * ^Á @~ |áÀ^Áæð * Á] ^ìæ | ÈQ | Áç|Áãç •
 , æ@Àçæ~ { Á^æ æ ^Á^ } • [| Áç áÁ æ } ð * Á^çæÈ • ç@Á æ } æÁ æ@ç
 ç • ç , æ&@ | çæ^àÈ

I ÈV | ÁæðÁãç * È~ ç@Áãç * Á æ ç | Áð | Á ç Á@Á ç òÁQ [\ È^] ç | Á@Áãç |
 & | | & ç Á } Á@Á æ Èç áÁ æ ^Á ^Á æ | Á^ æ ç | Áð | Á^ •] ^ } • ð } Á
 • dæ @Á áÁ [ç , æ ç áÁ | Á ð | ^àÈ

I ÈT æ ^Á ^Áçæ~ { Á æ • Á^Áç^ | ^Á } æ^áÁ ç | Á@Á^ } • çÁ áÁ æ çÁ Á@
 | | æ ÈV à • ^ÁçÁ@Á æ Á ç | æ * Áæ | ^Á Á@ Á æ } æÈ

I ÈU • çÁ áÁ | ^ • Á^ • çÁ Á^ • çÁ ç } Á Á@ & Á Áæç | Èæ @Á áÁQ | Á^
 [] ^ìæ | Á^ | ^Á æ ÁãçÈQ | Á áÁ æ @Á^Á ç | { æ } ç Áæç^ È^ æ á
 | ^ • Á æ çÁ Á æ ç òçæ~ { ÈÁ áÁæ • Á , Á^ç | Á Áæç | ÈÁ Á^ Á
 |] | æ Á^ , ÁXÁð [Áæç | È

I ÈY @ } Áæ Á | Áãç * Èæ^Á ç òÁ | Á æ^ÁQ [\ Á | , | Á Á àæç Á ææ
 çæ~ { Á | ÈQ | Áçæ~ { Á Á^ } ^ìæ áÁãç | Á Á Á^æ^Á & | ÈS , ^
 Q [\ È | æ ^ } Á æ áÁ] ^æ & | È

I ÈY @ } Áçæ~ { Á Á àæç^áÈç áÁãç | Á ç • Áæ ð * Á@Á æ È ç | Á@Á ç ^
 [| Á ç òÁ áÁ æ ^Á ^Á æ Á@ÁQ | áá * Áçæ~ { Á Áæ | Á áÁ@Á@Á æ
 æ Áæ æ & áÈQ@Á æ Á } Á@Áçæ~ { Áæ * ^Á | , | Á æ | Á Á | È [^
 æ Á ç Á } • æ^Áçæ~ { Á | á Á [• • æ | Á ^Á Á ç Á] ^ìæ & çæ~ { Á^æ Á |
 æ Á^ ç } ^ } ç æ } & ç | ÈS , ^Á@ÁQ [\ È & Á@Á^æ È Á È [• æ } Á@
 | áç | Á áÁ] ^æ@Á & | ÈQÁç | Á } ç ^Á Á^æ È } • | ç Á [^ à^
 • Q [ç * Á | & á | ^Á Á ç æ æ ÈQ | áá * Áçæ~ { Á] ^æ • Áæ | È
 & | ç ^Á ÁãÈ

J ÈQ@Áçæ~ { Á^æ æ ^Á^ } • [| Á Áæçæ^áÁ @Á@Á æ Á^ •] ^ } á^áÈ ç
 ç Á æ Á , } Á áÁ^ç | { ð ^Á@Áæ } Á | Áçæ~ { Á^æ æ ^È

F ÈY @ } Áæ Á Á^ ç | æ Á , } È , ^Á@ÁQ [\ Á } ç Á@Áãç |
 • æ | Á æ ç | Áð | Á^ •] ^ } • ð } Á Á | æ ^ } Á [] | ç | È , Áæ^Á@ÁQ [\
 [Á ç Á | Á ç òÁ áÁ@Áãç | Á æ Á^Áãç áÁ [Á@Á æ È



3. OPERATING INSTRUCTIONS

CAUTION Residual vacuum can be present at the vacuum pads. Lift slowly until pads are free from the load.

~ Òì[] } ^[~ • Á^ ^

ÈÖ[] Á[ó@æ à|^Á[æ• Á ã@Á@æ ^È^ á^È^ æ• Áæ áÁ^ { } ^|æ ^È^ æÈ@æÁæ
á & { } ææ|^Á ã@Á@Áæ|^• Á Á@Áæá, [|^Á ^&æ ææÁæ~ { Áæ^È

ÈÖ[] Á[ó@æ à|^Á[æ• Á ã@Áæ Áæ@|^) & Á^|~æ^È^ æ@Á Á[áæ|^Á[Á] @|^
@Á|^á Á|^•~|^Á Á@Áæá, [|^Á ^&æ ææÁæ~ { Áæ^È

ÈÖ[] Á[ó@æ à|^Á} \} [], } Á æ|^æ• Á} |^• Á[~ Á@æ^Áæ|^á áÁ^ ~ ó] ^&æ
&æ ææÁ æá^• æ & Á^• È

~ Ùq|^æ^Á Áæ^È

FÈY @} Á@Áæ^Á Á[ó^áá * Á^• áÈÁ[Á[ó^æ^Á^•] ^} á^áÁ[{ Á@Á@[] È
Ù~ Á^Á[, } Á} Á Áæ|^á * Áæ áÈÁææ * Áæ^Á^•] ^} á^áÁ[Á[} * Á|^á á•
, ã@~ Á^Á[æÁ&æ Áæ^• Áæ æ^Á Á@Á ç|^} æÁææ @æ { ÈÖÁ Á^• ó
• ç|^Á@Áæ^Á ã@Á@Áæ~ { Á æÁ^æá * Á^• Á^ Á@áÁ^Áæ È
• }] [|^á Á~Á@Á[[] È

GÈS^^) Á@Á|^Áæç^Á Á@Á^Á@^Á[• æ } Á @} Á[ó^Á] ^|æ } È
Öæ & { } ^&@Á@Áæ^Á[{ Á@Á[, ^|Á[~|^ÈÖæ & { } ^&@Á@Áæ * Á[, ^|
]] * Áæ^Á@Áæ|^Á Á^||^ Á^&æ^á

HÈÙq|^Áæ^Á • æ^ÈÖ|^æ Á@Áæ~ { Áæ^Áæ áÁ@Á @|^Á~ á { } ó[{
æ^ Á^á^ÈÖç[æÁ^ Á} çá[{ } ^} óç[• áÁ[Áæ }] • Á|^Á Á & { } ^} c
, ^æ@È

~ Uç^|^æ * Áæ|^

V@Á[||, } * Á[æÁç^|^ @æ * Áæ|^• Áæ^Á^• á } ^áÁ[!Á|^] ^• Á Áæ~ { Á
|^Á^Á[Á^Á[{ } á^Á@Á { } á|^Á Áæ~ { Á æÁ^~ á^áÁ Á@æ à|^Á|^• Á|^
{ ^æÁ @^Áæ áÁ|^È

Ø|^Áæá, [|^Á ^&æ ææÁæ~ { Áæ^È@Áæ|^• Áæ Áæ[Á^
|^Á|^á Á^Á[} á } Á@Áç^|^ @æ * Á Áæ|^È



3. OPERATING INSTRUCTIONS

[illegible][illegible]

P^æ^ Áœ Á | æ^ Áœ Á ~ æ } á d^ & c | æ Á æ æ Á ~ & @ œ œ Á ^ & d } Á æ á Á
] ^ á | * Á æ Á | { Á ç | œ * Á Á ^ | á æ | Á [á á | : á | Ê Á [, ^ ç | Ê Á æ Á Á Á
á á æ | á Á | ç | Á á * | Á á Á | Á æ * Á Á @ ^ Ê

GLASS SHEET		
Thickness (mm)	Weight (kg/m ²)	Overhang 'L' (cm)
4	8	50
5	10	65
7	20	75
8	20	80
10	25	90
13	30	100
16	40	120
20	50	130
23	60	140
26	70	150


STEEL SHEET & PLATE GAUGE			
Standard Steel Thickness (mm)	Weight (kg/m ²)	Overhang 'L'	
		50mm deflection (cm)	125mm deflection (cm)
0.5	4	35	50
0.6	5	40	55
0.8	6	45	60
1.0	8	55	70
1.2	9	60	75
1.5	12	65	85
1.8	14	70	90
2.0	16	75	95
2.5	20	85	100
3.0	24	95	120
4.0	31	100	130
5.0	39	120	150
6.0	47	140	170
8.0	63	150	190
9.0	71	160	220
10.0	79	175	225
11.0	86	185	230
12.0	94	195	245
15.0	118	200	255
16.0	126	220	275
18.0	141	230	290
19.0	149	240	300
22.0	173	260	325
25.0	196	280	350



3. OPERATING INSTRUCTIONS


- Load Overhang Calculation

SINGLE PAD LIFTERS




Single pad vacuum lifters are normally used to lift and transport single sheets of manageable dimensions. These dimensions vary greatly depending upon the material and application, and must be decided by the end user. AARDWOLF recommends the use of single pad lifters only on rigid or fairly rigid materials and where the operator can conveniently place the lifter in the center of the load. Even if the material is thick and light, such as foam core aluminum panels, a single pad lifter is difficult to center over a six foot or greater edge-to-edge load distance. A multiple pad lifter should be selected.

MULTIPLE IN-LINE LIFTERS



Large loads, or a load with a length dimension of two or three times its width, are best handled with a multiple-pad lifter. When possible, a center-cup to center-cup distance of one half, but not less than one third, of the length of the load should be chosen. When lifting a load with three pad, in-line lifter, the center-cup to center-cup dimension must be one third the length of the load to obtain correct load distribution.

MULTIPLE PAD LIFTER WITH CROSS-ARMS



Large or flexible loads are best handled with two or more rows of pads suspended from two or more cross-arms. For best balance and safety, each cup must carry the same share of the load. The cups must be evenly spaced along the width and length of the load for equal loading of the pads.

A 50 mm deflection or sag is the maximum we recommend for safe load handling. Equal loading of pads should be determined for the longest, widest load to be handled. Some limp or flexible materials require more support points to ensure level load handling. For every flexible materials, the overhang must be less than shown on the chart. Though we recommend near level load handling, the end user must determine the acceptable overhang for their application.

- Inspection and maintenance guides

A comprehensive checklist of inspection and maintenance is contained on page... in this manual. It is intentionally designed to support the operator to monitor the condition of lifter. Additionally, it is strongly recommended to follow the inspection and maintenance regulations stipulated by local authorities. Failures to carry out the inspection and maintenance could result in human and material losses. Aardwolf Industries LLC denies any claims due to such losses.

CAUTION Maintenance service must not be carried out if the lifter and/or battery is being connected to power source.



3. OPERATING INSTRUCTIONS

• Inspection schedule

Before every lift: the following lifter components should be examined before a lifting operation is carried out:

- Vacuum pad
- Load surface

Frequent period (20-40 hours use or one-month out-of-service): the following lifter components should be examined before a lifting operation is carried out:

- Lifter structure
- Vacuum system (including a vacuum test)

Do not carry out any lifting operation if any issues are found until the solution is provided and taken.

NOTE In case the lifter is not used less than a day in a 2-week period, the inspection should be performed before using the lifter.

• Testing schedule

A lifting test including the vacuum test, the pumping test, and the load test should be performed to ensure that the lifter is in a good condition before using the lifter. If any issues are found, stop using the lifter until the solution is provided and taken.

• Load test

This test is purposed to prove the maximum lifter capacity can be reached without failure.

- Employ a load test with a maximum weight that meet the load capacity of lifter.
- Attach the pad onto the load with an Overhang as mentioned above.

3. OPERATING INSTRUCTIONS

- Do the uplifting of load to a minimal distance to ensure the lifting is totally supported.
- Hold the load in five minute. If the lifting is failed, conduct a vacuum test and inspect the vacuum pad and load surface. Do not use the lifter until the solution is provided and taken.

• Vacuum test

This test is purposed to detect any vacuum-related issues such as vacuum leakage.

- Cleaning the pad contact surface.
- Attach the lifter to a load with a clean, smooth and nonporous surface and with a curvature that is no more than the deflection as mentioned in the Overhang table.
- Leave the pad attached to the pad surface. If the vacuum drops down at a 10% reduction in vacuum for VLD - 02 or 20% reduction in a vacuum for VLD - 02 with a leakage rate of less than 3.8cm Hg (1.5"Hg) per second, the alarm will be activated until a sufficient increase in vacuum is achieved.
- If the lifter fails the vacuum test, do not use it until the issues are detected and the solution is provided and taken.

• Vacuum pad maintenance

- Friction coefficient

The friction coefficient represents the ability of pad to engage the load during the lifting operation. The load capacity of most Aardwolf lifter is based on a friction coefficient of 1 (except for Flat lifters).

However, the ability of vacuum pad may be reduced by factors such as contamination, wear, aging and exposure to sunlight as well as the conditions of load surface.



3. OPERATING INSTRUCTIONS

Moreover, the rubber of pad may be effected by other elements such as working environment, which cause reduce the life of pad.

Therefore, it is strongly recommended that the pads should be replaced with a new, original one on a regularly 2-year basis to ensure the friction coefficient is not compromised.

Contact Aardwolf staff for more information.

- Pad inspection

To increase the life of rubber pad and to ensure the friction coefficient, the inspection of pad should follow the inspection schedule as mentioned above. Paying attention to the following elements that may effect on the pad:

- + Contaminants on the pad surface or sealing edge: soils can prevent pads from adequately attaching or reduce the friction coefficient.
- + Filter screen helps prevent debris from plugging the vacuum hose and air filter. If missing, replace with a new, original one.
- + Nicks, cuts or abrasion on sealing edge or wear, stiffness or glaze of pad can reduce the lifting capacity of lifter. Replace with a new, original one.

- Pad cleaning

The cleaning of pad surface should be carried out on a regular basis to remove oil, dust or any contaminants with acceptable cleaning agents including soapy water and other mild cleansers.

Never use solvents, petroleum-based products including kerosene, gasoline and diesel fuel or any hash chemical for cleaning.

Never use unauthorized rubber cleaners or conditioners, such as those intended for cleaning tires or vinyl surfaces, because those products can leave a hazardous film on vacuum pads which significantly reduces their lifting capacity. The use of any unauthorized cleaning agent is prohibited because it could damage the pad and/or create a hazard to the operator or others.

3. OPERATING INSTRUCTIONS

To prevent liquid from inflowing to the vacuum system during cleaning, cover the suction hole in the recess for the filter screen or make sure the pad faces downward.

Use a clean sponge or lint-free cloth to apply an authorized cleanser and wipe the pad face clean.

A toothbrush (or similar brush with bristles that do not harm rubber) may be used to remove contaminants clinging to sealing edges.

Wipe all residue from the pad face, and allow the pad to dry completely before using the lifter.

• Checklist of maintenance items

Inspect shackle/master link and suspension stud. Replace any worn or defective parts.

Check vacuum gauge(s) to make sure the dial has an uninterrupted travel. Make sure the capacity indication is clearly visible.

Check vacuum lifter on vacuum holding by lifting an absolutely clean, flat, nonporous, rigid test load and note amount of vacuum obtained at the start of the lift. If drop in vacuum is less than 10% within 4 min of initial vacuum, the lifter is in satisfactory condition for use. If vacuum drop is in excess of 10%, the lifter is unsafe and should be checked to find out the reason for vacuum leakage.

Tighten all clamps and lifting and replace damaged or worn parts. Check the air inlet valve on the top of cylinder cover to make sure that the valve disc is loose.

If any malfunctions are observed, check the trouble shooting procedure or contact your nearest Aardwolf service engineer or Aardwolf Industries LLC for service.

Dated records of inspection and maintenance should be kept by an appointed, responsible personnel.

A faulty or damaged vacuum lifting device shall be removed from service for repair. Return to service only after the defect has been



3. OPERATING INSTRUCTIONS

corrected by an approved method using approved parts or materials as specified by the manufacturer.

• Trouble shooting Procedures for Aardwolf Mechanical Vacuum Lifters

1. Multi-pad Lifter with Vacuum Generators

The Aardwolf Lifter has been engineered and built to provide trouble-free, satisfactory use. They are carefully checked and tested before they are shipped.

The following trouble shooting procedures will help you to correct any equipment problems which might occur.

The problem and their corrections are listed in the order of probability and should be checked in this order.

2. Trouble shooting procedures for AARDWOLF Mechanical Vacuum Lifters :

◇ Problem - lifter slowly loses vacuum

2.1. Possible cause - damaged sealing rings:

- a. Check sealing rings for any cuts in lip or sealing ridges.
- b. Discard damaged seals immediately and replace with new ones.
- c. Clean the underside of sealing rings especially the sealing ridges, dirt may be trapped between sealing ring and grooves in vacuum pads.

2.2. Possible cause - surface condition of load:

- a. Surface has debris, heavy corrosion or mill scale.
- b. Use the lifter on clean loads and brush off loose debris, dirt, scale, chips, etc.
- c. Do not use the lifter on badly rusted, pitted, or very scaly surfaces of loads.



2.3. Possible cause - damaged to plumbing:

- a. Check flexible vacuum tubing for cuts or tears.
- b. Check for loose fittings or hose of clamps.
- c. Replace damaged tubing, pipe or fittings.
- d. All pipe threads must be sealed with a pipe thread sealant.

2.4. Possible cause - loose or damaged vacuum gauge:

- a. Replace damaged vacuum gauge.
- b. When replacing gauge, use sealant on threads to insure tight seal.

3. Trouble shooting procedures for Aardwolf Mechanical Vacuum Lifters

3.1. Possible cause - dirty valve seat or loose or damaged rubber valve disc on piston rod valve assembly:

- a. Lift piston out of cylinder housing and check and clean the valve seat.
- b. If the valve seat is damaged, disassemble generator, following instruction in manual.
- c. Replace old or damaged valve sealing disc.

3.2. Possible cause - damaged vacuum generator:

- a. The Structural damage to the vacuum generator housing or to the flange of a vacuum pad may cause a loss of vacuum.
- b. Consult factory for replacement or repair of damaged components.



3. OPERATING INSTRUCTIONS

◇ Problem - lifter rapidly loses vacuum:

3.3. Possible Cause - misapplication of lifter.

- a. Load may be too heavy or too dirty.
- b. Pads may not be completely seated on load surface or may be covering holes or welds.
- c. The load's length may be too longer than that of lifter. See the load overhang tables.
- d. Operator lifter following all instructions and safety rules in this manual.

3.4. Possible Cause - damaged sealing diaphragm.

- a. If piston failed to 'bottom out' and has been forced down or if a load was suddenly dropped, the sealing diaphragm may be torn.
- b. Never start disassembling vacuum generator without consulting your instruction manual.
- c. Remove the outer circle or bolts on housing cover and lift out piston assembly.
- d. Check for damaged to diaphragm. (See disassembly instructions).e. The most likely area for damaged the diaphragm is adjacent to the hold-down clamping ring.
- f. Replace torn diaphragm following procedure indicated in disassembly instructions.

3.5. Possible Cause - shut off valve left open for pads not used.

- a. Make certain shut off valves are completely closed to any vacuum pads not in use.
- b. Make certain shut off valves are completely open to any vacuum pads being used.



3. OPERATING INSTRUCTIONS

◇ Problem - mechanical malfunction of lifter, lifter does not operator

3.6. Possible cause - Misapplication of lifter, the lifter is being used on loads that are not suitable for handling

- a. Lifter should be used only on nonporous materials.
- b. Make certain shut off valves are completely open to any vacuum pads being use.

4. Troubleshooting Procedures for Aardwolf Mechanical Vacuum Lifters

◇ Problem - piston fails to 'Bottom-out'

4.1. Possible cause - improper lubrication or foreign material on the diaphragm.

- a. Reference instructions for disassembling / assembling of M100M generator information.
- b. Wipe off old lubricant with clean cloth and re-lubricate with talcum powder, rubbing thoroughly into all exposed rubber surfaces.
- c. Do not use oil or lubrication where this could cause swelling of rubber parts.

4.2. Possible cause - cold weather can stiffen diaphragm when lifter is stored at 200F or below.

- a. If the lifter has been exposed to a cold environment (below 350F), the mechanical valve mechanism, sealing ring, and rolling diaphragm may be cold and stiff. To prevent damage to the internal rolling diaphragm, and to ensure proper sealing of the rubber sealing ring, allow the unit to remain in a heated area for a few hours prior to operation.
- b. If this is not possible 'cycle' lifter several times to relax the iaphragm and to make sure that the piston will 'bottom out'



3. OPERATING INSTRUCTIONS

4.3. Possible cause - damage to the generator housing may cause the piston to bind.

Consult factory for repair or replacement of housing.

• Replacing vacuum pads and sealing rings

A sealing ring is one of the most important parts of any vacuum lifter. The ability to maintain a tight vacuum bond with the load surface is critical to the operation of the lifter. However, the seals are susceptible to damage. Generally, a sealing ring fails for one of five reasons:

1. A cut, tear or excessive abrasion (due to wear or physical abuse).
2. Aging: Visible as excessive surface cracks or crazing due to ozone attack.
3. Hardening of the rubber due to ozone attack.
4. Compression set caused by improperly storing lifter.
5. Swelling of the rubber due to prolonged contact with certain hydrocarbons, i.e., oils or solvents.


Damaged seals should be promptly replaced. Defective seals should be disposed of. Most vacuum seals have their part number molded on the outside lip. Please check the proper seal number before ordering replacements.




3. OPERATING INSTRUCTIONS

• Instructions of disassembling and inspection of diaphragm


FOR MECHANICAL VACUUM LIFTER SERIES 250




1 Remove outer circle of hold down bolts located on top of the housing cover



2 Lift housing cover until it clears the piston rod.



3 Lift the piston assembly out of housing.



4 Check empty cylinder housing for rust, dirt, debris or damage. Clean interior and if necessary repaint cylinder walls and bottom with zinc chromate metal primer.



3. OPERATING INSTRUCTIONS



Roll the diaphragm down so that the top of the piston valve assembly body is visible and unscrew bolts.





Once all the bolts are removed, roll the diaphragm up and pull the diaphragm and clamping ring up off of the piston bottom. Separate the two and inspect the diaphragm for any tears or holes, especially along the lips. Roll the diaphragm inside and out to check both sides. Pull back the grooves in the diaphragm and check closely for tears, since this is where they may be hidden. (photos show tears along diaphragm lip).

If there is any damage, replace the diaphragm. If not, clean the diaphragm with a mild solvent or warm soapy water. Dry it thoroughly, lubricate with a fine talcum powder, and put aside.



Place piston assembly on clean area and check piston bottom plate for dirt or other obstructions. Clean with compressed air if necessary.

3. OPERATING INSTRUCTIONS




With your finger, feel around the upper edge of the piston bottom valve seat to check for a smooth surface. If any nicks, gouges, or defects are felt, replace the valve seat.

Unfasten the bolts on the mechanical valve assembly. Separate each haft to remove the piston rod. Push the valve sealing disc cover up with your fingers to be sure that it alternates freely between high and low position.



Examine the rubber disc cover for any cracks, rips, or tears. If any exist, peel it off the valve disc and replace it. If not, wipe the dirt and dust off the bottom of the disc cover. (photo shows rubber disc half peeled off of valve disc).



Check the thin gasket on the bottom for any tears. If damaged, replace. Reassemble the mechanical valve assembly. Secure the bolts using an 8mm hex key up to 15 ft-lbs in an alternating pattern.



3. OPERATING INSTRUCTIONS

Instruction for reassembly of generator

NOTE If any components or bolts are damaged or show signs of wear, they should be replaced (only with AARDWOLF approved fasteners). Clean all threads thoroughly, on bolts as well as on internal component threads, before reassembling.



Now place the diaphragm on the piston bottom with the tubing oriented as shown. Align it so the lip of the diaphragm rest evenly in the groove on the piston bottom. Run your finger along the edge of the diaphragm to ensure that it is resting evenly.




3. OPERATING INSTRUCTIONS

Insert the long bolts into the assembly and roll the diaphragm down over the piston bottom. Using the 5mm hex key, tighten the bolts to 10ft-lbs., securing the clamping ring to the piston bottom and the piston bottom to the bottom plate.

Once the clamping ring is tightly bolted down, pull the diaphragm flap back up and reinsert the piston rod assembly back into the generator body. Replace the generator housing extension, making sure that the air inlet valve notches are located on the top and not the bottom (circular orientation is irrelevant). Then take the housing cover and place it on the housing extension.

IMPORTANT Be sure that the groove in the housing cover is aligned with the housing extension so that it rests evenly and securely.



Insert 8mm bolts and finger tighten in a symmetric side to side manner before proceeding to torque tighten. In other words, tighten one screw, then tighten the one directly across from it (180°). This way the housing cover is evenly secured with an even distribution of pressure and it will be not pull to the one side.

If the bolts are not tightened this way, the cover can pull to one side and tear the diaphragm. Once all of the bolts are fastened, go around again in the same manner and tighten them to approximately 24-25ft-lbs., using the 8mm hexkey.

Secure the shackle to the generator by placing the shackle pin through the piston. Insert the lynch pin in the end of shackle pin. Diaphragm inspection and generator reassembly is complete.



3. OPERATING INSTRUCTIONS

FOR MECHANICAL VACUUM LIFTER SERIES 600



1 Remove the outer bolts on the housing cover.




2 Connect the lifter to a crane or hoist hook to slowly lift up the housing cover with piston.



3 Lift up the housing cover out of the cylinder housing. After checking the cylinder housing, continue to inspect the rubber diaphragm and piston.



4 Remove the inner bolts of housing cover to detach it from the rubber diaphragm.



5 Unscrew the bolts of the piston ring on the top of rubber diaphragm and take it out of the diaphragm. Roll up the diaphragm and take it out of the piston middle. Inspect the diaphragm for any tears or holes, especially along the slips.



3. OPERATING INSTRUCTIONS




- Roll the diaphragm inside and out to check both sides. Pull back the grooves in the diaphragm and check closely for tears, since this is where they may be hidden. If there is any damage, replace the original diaphragm.
- Check the coverage level of anti-friction powder to prevent the wear of diaphragm.
- Lift up the piston top out of the piston middle. Inspect the piston for any debris. Clean it with the compressed air if necessary.

Instruction for reassembly of generator



Place the diaphragm on the piston top and put the piston ring inside the diaphragm so that they match up to their screw holes to prevent from tearing the diaphragm.



Place the housing cover on the top of piston top and ensure all bolts match up, and firmly and securely fasten all bolts.



Place the housing cover on the piston middle and gently move it around the piston middle so that they match up to their screw holes to prevent from tearing the diaphragm.



3. OPERATING INSTRUCTIONS



5 Attentively screw each bolts of piston ring and piston cover in a firmly and securely manner.



6 Connect the housing cover to a crane or hoist hook and place it inside the housing and ensure that the diaphragm is not torn.



7 Attentively screw each bolts of housing cover in a firmly and securely manner.

The diaphragm inspection and generator reassembly are complete.

FOR MECHANICAL VACUUM LIFTER SERIES 1000 & 2200



1 Remove outer bolts of housing cover.



2 Connect the lifter to a crane or hoist hook to slowly lift up the housing cover with piston.



3 Place the housing body on a firm and clean ground or table support.

3. OPERATING INSTRUCTIONS



4

Remove the rolling system from the housing body



5

Unscrew inner bolts of housing cover to detach the housing cover out of the piston.



6

Unscrew bolts of O-ring to detach the diaphragm out of the piston.



7

- Roll the diaphragm inside and out to check both sides. Pull back the grooves in the diaphragm and check closely for tears, since this is where they may be hidden. If there is any damage, replace the original diaphragm.
 - Check the coverage level of anti-friction powder to prevent the wear of diaphragm.
- Lift up the piston top out of the piston middle. Inspect the piston for any debris. Clean it with the compressed air if necessary.

Instruction for reassembly of generator



1

Place the piston top on the housing, using wooden support legs to lift up the piston top.



3. OPERATING INSTRUCTIONS



- Place the diaphragm on the piston top, then position gently the housing cover on the diaphragm so that their screw holes match up to prevent from tearing the diaphragm, then firmly and securely fasten all bolts.
- Pull down the diaphragm, ensure the bolts of O rings, diaphragm and piston bottom match up and fasten all bolts in a firm and secure manner.



- Slowly place the piston body inside the house and ensure that the screw holes of piston body and housing match up to prevent from tearing the diaphragm. Fasten all bolts in a firm and secure manner.
- Connect the rolling system to the lifter in a firm and secure manner.
- The diaphragm inspection and generator reassembly are complete.

• Aardwolf Vacuum Leakage Detector VLD - 02

The Aardwolf Mechanical Vacuum Lifters are equipped with an Aardwolf Vacuum Leakage Detector VLD – 02.

It is powered by an independent Alkaline battery with the capacity of 9 v, monitoring the vacuum level automatically. It consists of a pressure sensor, an audible warning horn, red warning light, and vacuum unit switch, all controlled by a solid state microchip.

3. OPERATING INSTRUCTIONS

In event that the vacuum is lost during a lift, a loud horn sounds, and a red light flashes to warn the operator. The VLS-08 monitors vacuum level even if the operator is not looking at the lifter, a useful and popular option.

The system is packaged in a rugged polycarbonate enclosure with a 1/4" push-to-connect fitting for tubing connections.

During each lifting cycle the programmed 'intelligent' processor senses the peak vacuum level. From this point, a 10% loss (or 20% loss for VLS-08-20) of vacuum with a leakage rate of less than 1½ in. Hg per second from that peak level will trigger the horn and light, informing the operator of a leak. The alarm will not sound on the detach cycle as with other primitive systems using preset switches. Even the smallest leak anywhere in the system will be detected.

Features

- Advanced Solid State Circuitry with Micro-Controller
- Precise, Reliable, Board Mounted Vacuum Transducer
- LCD Digital Display of Vacuum Level in Inches of Hg
- Audible Warning Horn
- Bright Flashing Red LED Warning Light
- Push-to-Connect Vacuum Source Port to Connect to Vacuum Manifold
- Auxiliary Output Jack to Connect to Optional VLS-AUX Auxiliary Siren/Alarm
- Easy Access to Battery Compartment
- Low Battery "Chirp" Indicator
- Light / Horn / LCD Test Button
- Powered by One Standard 9V Lithium Battery (included)
- Weight: 0.2kg

The VLD-02 (series) vacuum leakage sensor is vacuum level differential detector which is preprogrammed to active the alarm at a 10% reduction in vacuum for VLD-02 or 20% reduction in a vacuum for VLD-02 with a leakage rate of less than 1.5"Hg per second. The alarm will continue until a sufficient increase in vacuum is achieved, indicating no additional leakage is present, or the indicated vacuum level drop below 5"Hg. The horn, LED (red light)



3. OPERATING INSTRUCTIONS

and LCD (digital display) can be tested by pressing and holding the “test button” for approximately 3 seconds. The unit is also equipped with a low battery indicator which will cause the horn to “chirp” and the LED to flash when battery power is low. The battery should be replaced immediately with a standard 9V lithium battery. The auxiliary output jack on the VLD-02 (series) is an open collector output which can be connected directly to the VLD-02 or another I/O device, such as an emergency stop function on a CNC control, through a solid state relay.

Replacement of 9V Alkaline battery

It is time to replace a new 9V Alkaline battery if the Red led indicator does not light when pressing the “Push To Test” button.

Remove two screws on the right side of vacuum leakage detector and replace a new battery.

Please follow the regulations of battery disposal stipulated by local authorities.

WARNING

The VLD-02 is designed to be a warning device for vacuum leakage detection. When properly installed on an Aardwolf vacuum lifter, the operator will be warned of a slow vacuum leakage and should have adequate time to safely lower the attached load. If the alarm signal is ignored and the lifting operation is continued, the vacuum loss may adversely affect the vacuum “hold”, possibly resulting in serious injury to the operator. The VLD-02 is not designed for neither effective in detecting fast leaks nor sudden failures of the vacuum system.

The vacuum level achieved, using a Mechanical Vacuum Generator, is weight sensitive, relative to the load and lifter weight, as well as the pad, manifold and generator volume.

Lighter loads will produce a lower vacuum reading, which may render the VLD-02 leakage sensor ineffective, as the achieved vacuum level approaches 6” of Hg.



3. OPERATING INSTRUCTIONS

CAUTION

This vacuum leakage warning device will not provide timely warning to the operator that a reduction in vacuum has occurred due to incorrect use of a vacuum lifter, such as overloading, lifting oversized loads, unbalanced lifting or improper operator of any kind.

• PS-150 Parking Stands

- Adjustable in four positions pull sideways, turn, let go and it locks in position.
- Spring-loaded locking mechanism snaps into position for onesided, quick adjustments.

These spring-loaded, adjustable, four position parking stands fulfill two functions:

- In the 'down' position, which is recommended when you store the lifter, they provide the support for the lifter so the rubber seals will not touch the ground. This helps prolong the life of the rubber seals by protecting them from the debris on the floor.
- In a folded in, out or up position, they provide a grab bar for positioning the lifter easily and precisely on the load from the side.

Parking stands folded down: Keep the rubber vacuum pads suspended above the ground when the lifter is stored. Extends the life of the rubber sealing rings

Parking stands folded in: For keeping it out of the way. A popular position when not in use.

Parking stands folded out: Can be used as 'positioning grab bars'. Extends the length of the lifter for pushing or pulling from the side.

Parking stands folded up: Can be used as 'positioning grab bars'.



Parking stands feature rugged steel construction

Part no. For use with

PS-150	Mechanical vacuum lifter up to 2000lb (909kg) capacity range and up to 190 inch (7.5M) beam length
--------	---

Even with above criteria, there are some exceptions, especially when it comes to lifters. Parking stands are not available for all lifters. Consult factory for further information.

CE - DECLARATION OF CONFORMITY

We declare that the product is in conformity with the following standard: The Machinery Directive 2006/42/EC.

NOTE It is the responsibility of the user to adapt to state or local laws. The end user is responsible to use the equipment safely in a manner that it is designed for and within the rated capacity of the unit.

MECHANICAL VACUUM LIFTER INSPECTION REPORT

Model No. _____ Serial No. _____

Inspector: _____ Date: _____

Condition Codes:

- ☐ EX Excellent, like new condition
- ☐ GD Good, used but no problem, well maintained
- ☐ FR Fair, shows some wear but is serviceable
- ☐ NW Needs work, limited usefulness, flag for maintenance
- ☐ UN Unfit, unsafe, unusable, do not use until fixed

NOTICE This document is intended solely as an aid to the inspector as a reminder of the most frequently occurring lifter problems. It by no means cover every problem that can possibly occur. The inspector must be alert for any other conditions which could affect safe use of the equipment.



1. GENERAL

1.1 Cleanliness ☐EX ☐GD ☐FR ☐NW ☐UN

- Lifter must be clean enough to observe condition and read gauges
- Lifter must be free of dirt or debris which could affect safe operation

1.2 Labels ☐EX ☐GD ☐FR ☐NW ☐UN

- Nameplate
- Load capacity; entire lifter, each cross-arm, each pad
- Operating instructions
- Safety rules
- Warnings
- "Tighten slides" warnings

2. GENERATOR - MECHANICAL

2.1 Lift Sling ☐EX ☐GD ☐FR ☐NW ☐UN

Check condition of shackle / master link suspension stud and pins

2.2 Fasteners ☐EX ☐GD ☐FR ☐NW ☐UN

Check tightness and condition

2.3 Welds ☐EX ☐GD ☐FR ☐NW ☐UN

Uniform and free of cracks or defects

2.4 Gauges ☐EX ☐GD ☐FR ☐NW ☐UN

Dial readability, glass, indicator, guard

2.5 Ball Valves ☐EX ☐GD ☐FR ☐NW ☐UN

Operation, labels, general condition

2.6 Vacuum Loss Sensor ☐EX ☐GD ☐FR ☐NW ☐UN

Operate test switch for light and horn

Check general condition, display clarity



3. STRUCTURAL

3.1 Welding ☐EX ☐GD ☐FR ☐NW ☐UN

- Check for cracks, corrosion, deformation, fatigue
- Check welds and adjacent metal for signs of cracked or spilled paint indicating "working" of the metal

3.2 Frame

Check these items for damage; bent, broken or missing parts; adjustability distortion

Main beam ☐EX ☐GD ☐FR ☐NW ☐UN

Cross-arm ☐EX ☐GD ☐FR ☐NW ☐UN

Sides ☐EX ☐GD ☐FR ☐NW ☐UN

Pad suspensions ☐EX ☐GD ☐FR ☐NW ☐UN
(Including plate, studs and springs)

Brackets ☐EX ☐GD ☐FR ☐NW ☐UN

Attachment ☐EX ☐GD ☐FR ☐NW ☐UN
(Check parking stand operation)

3.3 Fasteners ☐EX ☐GD ☐FR ☐NW ☐UN

Check condition and tightness of all fasteners, hand knobs and wing nuts

4. VACUUM SYSTEM

4.1 Pads ☐EX ☐GD ☐FR ☐NW ☐UN

Check for cuts, tears, wear, aging (cracks, crazing or hardening of the rubber), embedded dirt or chips, inner seal condition.

4.2 Hoses and Connections ☐EX ☐GD ☐FR ☐NW ☐UN

- Check for cracks, wear or abrasion especially near connections, cracked or damaged fittings
- Check tightness of all hose clamps
- Check for collapsed or kinked vacuum lines

4.3 Ball Valves ☐EX ☐GD ☐FR ☐NW ☐UN

Check operation, condition, broken or missing handles, labels



5. LIFTER OPERATION ☐EX ☐GD ☐FR ☐NW ☐UN

Lift test

- Lift clean, dry, smooth, no-porous load, preferably weighing the maximum rated lift capacity.
- Operation should result in a clean, smooth lift.
- All gauges and indicators should be visible to the operator and work normally.
- Watch and listen for:
 - + Drop in vacuum level
 - + Vacuum leaks
 - + "sticky gauges" or failure to return to zero
 - + Unequal pad loading/unequal spring compression

Measure and record:

Attach time: _____ sec.; Release time: _____ sec.

Vacuum loss sensor operation - if equipped with the VLS option

☐EX ☐GD ☐FR ☐NW ☐UN

- Place an object under one side of a pad to create a vacuum leak large enough to cause level of vacuum to drop but not at a rate faster than 2"Hg per sec. Lift load a minimum distance off floor. Watch the vacuum level drop and observe operation of the VLS system.
- Does it give timely warning before load drops?

6. OPERATOR QUALIFICATION AND SAFETY TRAINING

- Check operator training records.
- Are all operators trained per all rules and regulation stipulated by local authorities? ☐ YES ☐ NO
- Do all operators know who the "qualified, designated persons" are for safety and maintenance? ☐ YES ☐ NO
- Do all operators have printed copies of operating and safety rules? ☐ YES ☐ NO



COMMENTS

VACUUM LIFTER INSPECTION REPORT SUMMARY SHEET

Model No. Serial No.

Lift capacity:

Inspected by: Date: Approved by: Date:

Overall Condition:

☐ Excellent, ☐ Good, ☐ fair, ☐ Needs Works, ☐ Unfit

Are any items rated "UNFIT"?

Which Items? _____

Action:

☐ Repair and return to service.

☐ Return to factory for overhaul

☐ Other, _____

Tag lifter, "Out of service - DANGER - Do Not Use"

Authorization:

___ Return to service

Inspected and approved by: _____

Are any items rated “NEEDS WORK”?

Which Items? _____

Action:

___ Maintenance Scheduled For _____ Date _____

___ Return to Temporary Service Until _____ Date _____

Tag lifter, “Temporary Service Only”

___ Re-inspect Frequently: ___ Daily, ___ Weekly, ___ Other

Approved by: _____

COMMENTS



4. INSPECTION REPORT

MAINTENANCE RECORD

Always keep lifter clean and dry and free from debris. See maintenance instructions.


[illegible]

NOTES



5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL250-2 ASSEMBLY DIAGRAM



MECHANICAL VACUUM LIFTER
Code AMVL250-2
ASSEMBLY DIAGRAM


PARTS LIST			
No.	Code	Name Part	Qty.
01	AMVL250-001	Bow Shackles	01
02	AMVL250-002	Main spindle	01
03	AMVL250-003	Actuator shaft	01
04	AMVL250-004	Actuator pin $\phi 4$	02
05	AMVL250-005	Actuator lock	01
06	AMVL250-006	Actuator plate	01
07	AMVL250-007	Screw M6 x 12	01
08	AMVL250-008	Actuator rubber cover	01
09	AMVL250-009	O-ring 60 x 72 x 6	01
	AMVL250-010	Bolt M6 x 25	12
11	AMVL250-011	Top Housing	01
12	AMVL250-012	Bolt M6 x110	08
13	AMVL250-013	Top piston	01
14	AMVL250-014	Piston diaphragma	01
15	AMVL250-015	Middle piston	01
16	AMVL250-016	Bolt M10 x 50	08
17	AMVL250-017	Lift stop	02
18	AMVL250-018	O-ring 165 x 172 x 3.5	01
19	AMVL250-019	Bottom piston	01

PARTS LIST			
No.	Code	Name Part	Qty.
20	AMVL250-020	Bolt M10 x 20	02
21	AMVL250-021	Washer M10	02
22	AMVL250-022	Housing	01
23	AMVL250-023	Nut M8	04
24	AMVL250-024	Washer M8	12
25	AMVL250-025	Gauge guard	01
26	AMVL250-026	Bolt M5 x 16	04
27	AMVL250-027	Tailpiece male 1/4	02
28	AMVL250-028	Shaft Beam 60 x 60 x 1300	01
29	AMVL250-029	Plastic plate	02
30	AMVL250-030	U $\phi 8$ taro M8	04
31	AMVL250-031	Latch locking M6	04
32	AMVL250-032	Bolt M8 x 25	08
33	AMVL250-033	Air hose $\phi 6$	02
34	AMVL250-034	Tailpiece male 1/4	02
35	AMVL250-035	Bracket beam 60 x 60	02
36	AMVL250-036	Hub 300	02
37	AMVL250-037	Seal 300	02
37	AMVL250-037	Handle assembly	01



5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL250-4 ASSEMBLY DIAGRAM



MECHANICAL VACUUM LIFTER

Code AMVL250-4
ASSEMBLY DIAGRAM


PARTS LIST			
No.	Code	Name Part	Qty.
01	AMVL250-001	Bow Shackles	01
02	AMVL250-002	Main spindle	01
03	AMVL250-003	Actuator shaft	01
04	AMVL250-004	Actuator pin $\phi 4$	02
05	AMVL250-005	Actuator lock	01
06	AMVL250-006	Actuator plate	01
07	AMVL250-007	Screw M6 x 12	01
08	AMVL250-008	Actuator rubber cover	01
09	AMVL250-009	O-ring 60 x 72 x 6	01
10	AMVL250-010	Bolt M6 x 25	12
11	AMVL250-011	Top Housing	01
12	AMVL250-012	Bolt M6 x110	08
13	AMVL250-013	Top piston	01
14	AMVL250-014	Piston diaphragma	01
15	AMVL250-015	Middle piston	01
16	AMVL250-016	Bolt M10 x 50	08
17	AMVL250-017	Lift stop	02
18	AMVL250-018	O-ring 165 x 172 x 3.5	01
19	AMVL250-019	Bottom piston	01
20	AMVL250-020	Bolt M10 x 30	02
21	AMVL250-021	Washer M10	02
22	AMVL250-021	Housing	01

PARTS LIST			
No.	Code	Name Part	Qty.
23	AMVL250-023	Nut M10	08
24	AMVL250-024	Washer M10	08
25	AMVL250-025	Housing cover	02
26	AMVL250-026	Bolt M5 x 16	04
27	AMVL250-027	Shaft beam 60 x 60 x 2200	01
28	AMVL250-028	Filter pad	01
29	AMVL250-029	Filter	01
30	AMVL250-030	Connector 1/4 x 3	01
31	AMVL250-031	Air hose $\phi 13$	06
32	AMVL250-032	Bolt M12	16
33	AMVL250-033	Spring bushing	16
34	AMVL250-034	Bracket	04
35	AMVL250-035	Spiral spring	16
36	AMVL250-036	Connector 1/4	06
37	AMVL250-037	Hub 250	04
38	AMVL250-038	Seal 250	04
39	AMVL250-039	Beam 40x40x3	02
40	AMVL250-040	Bracket beam 40x40x3	02
41	AMVL250-041	Latch locking M6	04
42	AMVL250-042	U $\phi 10$ taro M10	04
43	AMVL250-043	Plastic plate	02
44	AMVL250-044	Handle assembly	01



5. SPART PART LIST

MECHANICAL VACUUM LIFTER
Code AMVL250-4 IN LINE
ASSEMBLY DIAGRAM



5. SPART PART LIST

MECHANICAL VACUUM LIFTER
Code AMVL250-4 IN LINE
ASSEMBLY DIAGRAM


PARTS LIST			
No.	Code	Name Part	Qty.
01	AMVL250-001	Bow Shackles	01
02	AMVL250-002	Main spindle	01
03	AMVL250-003	Actuator shaft	01
04	AMVL250-004	Actuator pin $\phi 4$	02
05	AMVL250-005	Actuator lock	01
06	AMVL250-006	Actuator plate	01
07	AMVL250-007	Screw M6 x 12	01
08	AMVL250-008	Actuator rubber cover	01
09	AMVL250-009	O-ring 60 x 72 x 6	01
10	AMVL250-010	Bolt M6 x 25	12
11	AMVL250-011	Top Housing	01
12	AMVL250-012	Bolt M6 x110	08
13	AMVL250-013	Top piston	01
14	AMVL250-014	Piston diaphragma	01
15	AMVL250-015	Middle piston	01
16	AMVL250-016	Bolt M10 x 50	08
17	AMVL250-017	Lift stop	02
18	AMVL250-018	O-ring 165 x 172 x 3.5	01
19	AMVL250-019	Bottom piston	01
20	AMVL250-020	Bolt M10 x 30	02

PARTS LIST			
No.	Code	Name Part	Qty.
21	AMVL250-021	Washer M10	02
22	AMVL250-022	Housing	01
23	AMVL250-023	Nut M10	08
24	AMVL250-024	Washer M10	08
25	AMVL250-025	Housing cover	02
26	AMVL250-026	Bolt M5 x 16	04
27	AMVL250-027	Shaft beam 60 x 60 x 2200	01
28	AMVL250-028	Filter pad	01
29	AMVL250-029	Filter	01
30	AMVP250-030	Connector 1/4 x 3	01
31	AMVL250-031	Air hose $\phi 13$	06
32	AMVL250-032	Connector 1/4	09
33	AMVL250-033	Bolt M12	16
34	AMVL250-034	Washer M12	16
35	AMVL250-035	Bracket	04
36	AMVL250-036	Hub 250	04
37	AMVL250-037	Seal 250	04
38	AMVL250-038	$\phi 10$ taro M10	04
39	AMVL250-039	Plastic plate	02
40	AMVL250-040	Handle assembly	01



5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL250-8 ASSEMBLY DIAGRAM



5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL250-8 ASSEMBLY DIAGRAM


PARTS LIST			
No.	Code	Name Part	Qty.
01	AMVL250-001	Bow Shackles	01
02	AMVL250-002	Main spindle	01
03	AMVL250-003	Actuator shaft	01
04	AMVL250-004	Actuator pin $\phi 4$	02
05	AMVL250-005	Actuator lock	01
06	AMVL250-006	Actuator plate	01
07	AMVL250-007	Screw M6 x 12	01
08	AMVL250-008	Actuator rubber cover	01
09	AMVL250-009	O-ring 60 x 72 x 6	01
10	AMVL250-010	Bolt M6 x 25	12
11	AMVL250-011	Top Housing	01
12	AMVL250-012	Bolt M6 x110	08
13	AMVL250-013	Top piston	01
14	AMVL250-014	Piston diaphragma	01
15	AMVL250-015	Middle piston	01
16	AMVL250-016	Bolt M10 x 50	08
17	AMVL250-017	Lift stop	02
18	AMVL250-018	O-ring 165 x 172 x 3.5	01
19	AMVL250-019	Bottom piston	01
20	AMVL250-020	Bolt M10 x 30	02

PARTS LIST			
No.	Code	Name Part	Qty.
21	AMVL250-021	Washer M10	02
22	AMVL250-022	Housing	01
23	AMVL250-023	Nut M10	08
24	AMVL250-024	Washer M10	08
25	AMVL250-025	Housing cover	02
26	AMVL250-026	Bolt M5 x 16	04
27	AMVL250-027	Shaft beam 60 x 60 x 2200	01
28	AMVL250-028	Filter pad	01
29	AMVL250-029	Filter	01
30	AMVL250-030	Connector 1/4 x 3	01
31	AMVL250-031	Air hose $\phi 13$	06
32	AMVL250-032	Connector 1/4	09
33	AMVL250-033	Beam 40 x 40 x 3	04
34	AMVL250-034	Bracket	04
35	AMVL250-035	Tee connector 1/4	04
36	AMVL250-036	SF 150	08
37	AMVL250-037	U $\phi 10$ taro M10	04
38	AMVL250-038	Plastic plate	02
39	AMVL250-039	Handle assembly	01



5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL600-2 ASSEMBLY DIAGRAM




MECHANICAL VACUUM LIFTER Code AMVL600-2 ASSEMBLY DIAGRAM

PARTS LIST			
No.	Code	Name Part	Qty.
1	AMVL600 - 001	Bow shackle	01
2	AMVL600 - 002	Main spindle	01
3	AMVL600 - 003	Actuator	01
4	AMVL600 - 004	Eye bolt M8	02
5	AMVL600 - 005	Valve locking	01
6	AMVL600 - 006	O-ring 40 x 47 x 3.5	01
7	AMVL600 - 007	Bolt G3/4	01
8	AMVL600 - 008	O-ring 50 x 60 x 5	01
9	AMVL600 - 009	Bolt M6 x 20	46
10	AMVL600 - 010	Top housing	01
11	AMVL600 - 011	Piston diaphragm	01
12	AMVL600 - 012	Piston small	01
13	AMVL600 - 013	Piston ring	01
14	AMVL600 - 014	Bolt M10 x 65	08
15	AMVL600 - 015	Lift stop	01
16	AMVL600 - 016	Bottom piston	01
17	AMVL600 - 017	Housing	01
18	AMVL600 - 018	Washer M10	16
19	AMVL600 - 019	Bolt M10 x 35	06
20	AMVL600 - 020	Box cover	01
21	AMVL600 - 021	Bolt M3 x 12	04
22	AMVL600 - 022	Nut M10	08
23	AMVL600 - 023	Filter pad	01
24	AMVL600 - 024	Filter 3/4	01
25	AMVL600 - 025	Main bar 1300	01
26	AMVL600 - 026	Air hose ϕ 13	06
27	AMVL600 - 027	Connection 1/4 x 2	01
28	AMVL600 - 028	Bolt M12 x 35	08
29	AMVL600 - 029	Washer M12	08
30	AMVL600 - 030	Connection 1/4	05
31	AMVL600 - 031	Suction bracket	02
32	AMVL600 - 032	Latch locking M6	04
33	AMVL600 - 033	Hub 350	04
34	AMVL600 - 034	Seal 350	02
35	AMVL600 - 035	Parking	02
36	AMVL600 - 036	U bolt M10	02
37	AMVL600 - 037	Support plate	02
38	AMVL600 - 038	Handle assembly	01

5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL600-4 ASSEMBLY DIAGRAM



MECHANICAL VACUUM LIFTER
Code AMVL600-4
ASSEMBLY DIAGRAM


PARTS LIST			
No.	Code	Name Part	Qty.
1	AMVL600 - 001	Bow shackle	01
2	AMVL600 - 002	Main spindle	01
3	AMVL600 - 003	Actuator	01
4	AMVL600 - 004	Eye bolt M8	02
5	AMVL600 - 005	Valve locking	01
6	AMVL600 - 006	O-ring 40 x 47 x 3.5	01
7	AMVL600 - 007	Bolt G3/4	01
8	AMVL600 - 008	O-ring 50 x 60 x 5	01
9	AMVL600 - 009	Bolt M6 x 20	46
10	AMVL600 - 010	Top housing	01
11	AMVL600 - 011	Piston diaphragma	01
12	AMVL600 - 012	Piston small	01
13	AMVL600 - 013	Piston ring	01
14	AMVL600 - 014	Bolt M10 x 65	08
15	AMVL600 - 015	Lift stop	01
16	AMVL600 - 016	Bottom piston	01
17	AMVL600 - 017	Housing	01
18	AMVL600 - 018	Washer M10	16
19	AMVL600 - 019	Bolt M10 x 35	06
20	AMVL600 - 020	Box cover	01
21	AMVL600 - 021	Bolt M3 x 12	04
22	AMVL600 - 022	Nut M10	08
23	AMVL600 - 023	Filter pad	01

PARTS LIST			
No.	Code	Name Part	Qty.
24	AMVL600 - 024	Filter 3/4	01
25	AMVL600 - 025	Main bar 1300	01
26	AMVL600 - 026	Air hose Ø13	08
27	AMVL600 - 027	Tee connection 1/4	01
28	AMVL600 - 028	Connection 1/4 x 2	01
29	AMVL600 - 029	Latch locking	04
30	AMVL600 - 030	Suction bracket	04
31	AMVL600 - 031	Bolt M12 x 160	16
32	AMVL600 - 032	Top bushing	32
33	AMVL600 - 033	Spring 2.5 x 60	16
34	AMVL600 - 034	Middle bushing	16
35	AMVL600 - 035	Spring 1.5 x 60	16
36	AMVL600 - 036	Bottom bushing	32
37	AMVL600 - 037	Hub 300	04
38	AMVL600 - 038	Seal 300	04
39	AMVL600 - 039	Connection 1/4	04
40	AMVL600 - 040	Parking	02
41	AMVL600 - 041	Beam 40 x 40 x 3	02
42	AMVL600 - 042	Latch locking M6	04
43	AMVL600 - 043	Beam bracket	02
44	AMVL600 - 044	U bolt M10	04
45	AMVL600 - 045	Support plate	02
46	AMVL600 - 046	Handle assembly	01



5. SPART PART LIST


MECHANICAL VACUUM LIFTER Code AMVL600-4 IN LINE ASSEMBLY DIAGRAM



MECHANICAL VACUUM LIFTER Code AMVL600-4 IN LINE ASSEMBLY DIAGRAM

PARTS LIST			
No.	Code	Name Part	Qty.
1	AMVL600 - 001	Bow shackle	01
2	AMVL600 - 002	Main spindle	01
3	AMVL600 - 003	Actuator	01
4	AMVL600 - 004	Eye bolt M8	02
5	AMVL600 - 005	Valve locking	01
6	AMVL600 - 006	O-ring 40 x 47 x 3.5	01
7	AMVL600 - 007	Bolt G3/4	01
8	AMVL600 - 008	O-ring 50 x 60 x 5	01
9	AMVL600 - 009	Bolt M6 x 20	34
10	AMVL600 - 010	Top housing	01
11	AMVL600 - 011	Piston diaphragma	01
12	AMVL600 - 012	Piston small	01
13	AMVL600 - 013	Piston ring	01
14	AMVL600 - 014	Bolt M10 x 65	08
15	AMVL600 - 015	Lift stop	01
16	AMVL600 - 016	Bottom piston	01
17	AMVL600 - 017	Housing	01
18	AMVL600 - 018	Bolt M10 x 25	02
19	AMVL600 - 019	Washer M10	02
20	AMVL600 - 020	Box cover	01
21	AMVL600 - 021	Bolt M3 x 12	04
22	AMVL600 - 022	Nut M10	08
23	AMVL600 - 023	Filter pad	01
24	AMVL600 - 024	Filter	01
25	AMVL600 - 025	Main bar 2200	01
26	AMVL600 - 026	Air hose $\phi 10$	06
27	AMVL600 - 027	Tee connection 1/4	01
28	AMVL600 - 028	Connection 1/4 x 3	01
29	AMVL600 - 029	Bolt M12 x 35	22
30	AMVL600 - 030	Washer M12	16
31	AMVL600 - 031	Bracket	04
32	AMVL600 - 032	Latch locking M6	08
33	AMVL600 - 033	Hub 300	04
34	AMVL600 - 034	Seal 300	04
35	AMVL600 - 035	Connection 1/4	06
36	AMVL600 - 036	Parking	02
37	AMVL600 - 037	U bolt M10	04
38	AMVL600 - 038	Support plate	02
39	AMVL600 - 039	Handle assembly	01

MECHANICAL VACUUM LIFTER Code AMVL600-8 ASSEMBLY DIAGRAM




MECHANICAL VACUUM LIFTER Code AMVL600-8 ASSEMBLY DIAGRAM

PARTS LIST			
No.	Code	Name Part	Qty.
1	AMVL600 - 001	Bow shackle	01
2	AMVL600 - 002	Main spindle	01
3	AMVL600 - 003	Actuator	01
4	AMVL600 - 004	Eye bolt M8	02
5	AMVL600 - 005	Valve locking	01
6	AMVL600 - 006	O-ring 40 x 47 x 3.5	01
7	AMVL600 - 007	Bolt G3/4	01
8	AMVL600 - 008	O-ring 50 x 60 x 5	01
9	AMVL600 - 009	Bolt M6 x 20	42
10	AMVL600 - 010	Top housing	01
11	AMVL600 - 011	Piston diaphragma	01
12	AMVL600 - 012	Piston small	01
13	AMVL600 - 013	Piston ring	01
14	AMVL600 - 014	Bolt M10 x 65	08
15	AMVL600 - 015	Lift stop	01
16	AMVL600 - 016	Bottom piston	01
17	AMVL600 - 017	Housing	01
18	AMVL600 - 018	Washer M10	16
19	AMVL600 - 019	Bolt M10 x 35	06
20	AMVL600 - 020	Box cover	01
21	AMVL600 - 021	Bolt M3 x 12	04
22	AMVL600 - 022	Nut M10	08
23	AMVL600 - 023	Filter pad	02
24	AMVL600 - 024	Filter	02
25	AMVL600 - 025	Main bar 2200	01
26	AMVL600 - 026	Connection 1/4 x 3	02
27	AMVL600 - 027	Tee connection 1/4	02
28	AMVL600 - 028	Air hose ϕ 10	12
29	AMVL600 - 029	Connection 1/4	12
30	AMVL600 - 030	Suction pad SF200	08
31	AMVL600 - 031	Horizontal bar	04
32	AMVL600 - 032	Latch locking M8	16
33	AMVL600 - 033	Parking	02
34	AMVL600 - 034	U bolt M10	04
35	AMVL600 - 035	Support plate	02
36	AMVL600 - 036	Handle assembly	01
34	AMVL600 - 034	Pin ϕ 10	02
35	AMVL600 - 035	Bracket support bar	02
36	AMVL600 - 036	Support bar	02

5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL600-10 ASSEMBLY DIAGRAM



MECHANICAL VACUUM LIFTER Code AMVL600-10 ASSEMBLY DIAGRAM


PARTS LIST			
No.	Code	Name Part	Qty.
01	AMVL600-001	Main spindle	01
02	AMVL600-002	Bolt M8 x 25	08
03	AMVL600-003	Guide Bushing	01
04	AMVL600-004	Bolt M10 x 50	08
05	AMVL600-005	Lift stop	01
06	AMVL600-006	Actuator	01
07	AMVL600-007	Bottom piston	01
08	AMVL600-008	Bolt M18 x 90	04
09	AMVL600-009	Spring washer M18	10
10	AMVL600-010	Washer M18	14
11	AMVL600-011	Rolling	02
12	AMVL600-012	Nut M18	06
13	AMVL600-013	Pin $\phi 20$ - M18	01
14	AMVL600-014	Chain $\phi 8$	02
15	AMVL600-015	Plate 12	02
16	AMVL600-016	Bushing M20 x 8	04
17	AMVL600-017	Housing cover	01
18	AMVL600-018	Bolt M6 x 25	28
19	AMVL600-019	Check valve	01
20	AMVL600-020	O - ring 47 - 40 - 3.5	01
21	AMVL600-021	Piston washer	01
22	AMVL600-022	Piston diaphragma	01
23	AMVL600-023	Top piston	01
24	AMVL600-024	Bolt M10 x 30	02
25	AMVL600-025	Washer M10	02
26	AMVL600-026	Housing	01
27	AMVL600-027	Washer M20	02
28	AMVL600-028	Spring washer M20	02
29	AMVL600-029	Bolt M20 x 110	02

PARTS LIST			
No.	Code	Name Part	Qty.
30	AMVL600-030	Nut M20	02
31	AMVL600-031	Connector	01
32	AMVL600-032	Vacuum gauge	01
33	AMVL600-033	Vacuum leakage sensor	01
34	AMVL600-034	Vacuum Guard	01
35	AMVL600-035	Washer M6	04
36	AMVL600-036	Bolt M6 x 12	04
37	AMVL600-037	Bolt M5 x 16	04
38	AMVL600-038	Handle assembly	01
39	AMVL600-039	Beam 50 x 50 x 5	04
40	AMVL600-040	Latch locking M10	04
41	AMVL600-041	Nut M24	10
42	AMVL600-042	Bushing top $\phi 25$	10
43	AMVL600-043	Spring $\phi 5$ x 96	10
44	AMVL600-044	Bushing top $\phi 25$ - 1	10
45	AMVL600-045	Bracket suction cup	10
46	AMVL600-046	Latch locking M10	10
47	AMVL600-047	Bushing bottom $\phi 25$	10
48	AMVL600-048	Spring $\phi 4$ x 116	10
49	AMVL600-049	Bushing bottom $\phi 25$ - 1	10
50	AMVL600-050	Suction cup	10
51	AMVL600-051	Beam 100 x 50 x 5	01
52	AMVL600-052	Air hose $\phi 12$	14
53	AMVL600-053	Cross connector 3/8	02
54	AMVL600-054	Tee connector 3/8	02
55	AMVL600-055	Clevis pin $\phi 20$	02
56	AMVL600-056	Support beam	02
57	AMVL600-057	Hair pin $\phi 5$	02



5. SPART PART LIST

MECHANICAL VACUUM LIFTER
Code AMVL1000-2
ASSEMBLY DIAGRAM



MECHANICAL VACUUM LIFTER Code AMVL1000-2 ASSEMBLY DIAGRAM

PARTS LIST


No.	Code	Name Part	Qty.
01	AMVL1000-001	Main spindle	01
02	AMVL1000-002	Bolt M8 x 25	08
03	AMVL1000-003	Guide Bushing	01
04	AMVL1000-004	Bolt M10 x 50	08
05	AMVL1000-005	Lift stop	01
06	AMVL1000-006	Actuator	01
07	AMVL1000-007	Bottom piston	01
08	AMVL1000-008	Bolt M18 x 90	04
09	AMVL1000-009	Spring washer M18	10
10	AMVL1000-010	Washer M18	14
11	AMVL1000-011	Rolling	02
12	AMVL1000-012	Nut M18	06
13	AMVL1000-013	Pin $\phi 20$ - M18	01
14	AMVL1000-014	Chain $\phi 8$	02
15	AMVL1000-015	Plate 12	02
16	AMVL1000-016	Bushing M20 x 8	04
17	AMVL1000-017	Housing cover	01
18	AMVL1000-018	Bolt M6 x 25	28
19	AMVL1000-019	Check valve	01
20	AMVL1000-020	O - ring 47 - 40 - 3.5	01
21	AMVL1000-021	Piston washer	01
22	AMVL1000-022	Piston diaphragma	01
23	AMVL1000-023	Top piston	01
24	AMVL1000-024	Bolt M10 x 35	02
25	AMVL1000-025	Washer M10	02

PARTS LIST

No.	Code	Name Part	Qty.
26	AMVL1000-026	Housing	01
27	AMVL1000-027	Washer M20	04
28	AMVL1000-028	Spring washer M20	02
29	AMVL1000-029	Bolt M20 x 110	02
30	AMVL1000-030	Nut M20	02
31	AMVL1000-031	Connector	01
32	AMVL1000-032	Vacuum gauge	01
33	AMVL1000-033	Vacuum leakage sensor	01
34	AMVL1000-034	Vacuum guard	01
35	AMVL1000-035	Bolt M6 x 12	04
36	AMVL1000-036	Washer M6	04
37	AMVL1000-037	Bolt M5 x 16	04
38	AMVL1000-038	Handle assembly	01
39	AMVL1000-039	Pin $\phi 14$ x 123	02
40	AMVL1000-040	Parking	02
41	AMVL1000-041	Circlip $\phi 14$	02
42	AMVL1000-042	Latch locking M20	02
43	AMVL1000-043	Bolt M16 x 30	08
44	AMVL1000-044	Washer M16	08
45	AMVL1000-045	Bracket suction pad	04
46	AMVL1000-046	Tailpiece male 3/8	04
47	AMVL1000-047	Hub 450	02
48	AMVL1000-048	Seal 450	02
49	AMVL1000-049	Beam 100 x 50 x 5	01
50	AMVL1000-050	Air hose $\phi 12$	04

5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL1000-4 ASSEMBLY DIAGRAM



5. SPART PART LIST


MECHANICAL VACUUM LIFTER Code AMVL1000-4 ASSEMBLY DIAGRAM

PARTS LIST			
No.	Code	Name Part	Qty.
01	AMVL1000-001	Main spindle	01
02	AMVL1000-002	Bolt M8 x 25	08
03	AMVL1000-003	Guide bushing	01
04	AMVL1000-004	Bolt M10 x 50	08
05	AMVL1000-005	Lift stop	01
06	AMVL1000-006	Actuator	01
07	AMVL1000-007	Bottom piston	01
08	AMVL1000-008	Bolt M18 x 90	04
09	AMVL1000-009	Spring washer M18	10
10	AMVL1000-010	Washer M18	14
11	AMVL1000-011	Rolling	02
12	AMVL1000-012	Nut M18	06
13	AMVL1000-013	Pin $\phi 20$ - M18	01
14	AMVL1000-014	Chain $\phi 8$	02
15	AMVL1000-015	Plate 12	02
16	AMVL1000-016	Bushing M20 x 8	04
17	AMVL1000-017	Housing cover	01
18	AMVL1000-018	Bolt M6 x 25	28
19	AMVL1000-019	Check valve	01
20	AMVL1000-020	O - ring 47 - 40 - 3.5	01
21	AMVL1000-021	Piston washer	01
22	AMVL1000-022	Piston diaphragm	01
23	AMVL1000-023	Top piston	01
24	AMVL1000-024	Bolt M10 x 30	02
25	AMVL1000-025	Washer M10	02
26	AMVL1000-026	Housing	01
27	AMVL1000-027	Washer M20	02
28	AMVL1000-028	Spring washer M20	02

PARTS LIST			
No.	Code	Name Part	Qty.
29	AMVL1000-029	Bolt M20 x 110	02
30	AMVL1000-030	Nut M20	02
31	AMVL1000-031	Connector	01
32	AMVL1000-032	Vacuum gauge	01
33	AMVL1000-033	Vacuum leakage sensor	01
34	AMVL1000-034	Vacuum Guard	01
35	AMVL1000-035	Bolt M6 x 12	04
36	AMVL1000-036	Washer M6	04
37	AMVL1000-037	Bolt M5 x 16	04
38	AMVL1000-038	Handle assembly	01
39	AMVL1000-039	Pin $\phi 14$ x 123	02
40	AMVL1000-040	Parking	02
41	AMVL1000-041	Circlip $\phi 14$	02
42	AMVL1000-042	Latch locking M10	02
43	AMVL1000-043	Beam 50 x 50 x 5	02
44	AMVL1000-044	Latch locking M20	04
45	AMVL1000-045	Bolt M12 x 185	16
46	AMVL1000-046	Bushing $\phi 30$	32
47	AMVL1000-047	Spring $\phi 4$ x 80	16
48	AMVL1000-048	Bushing $\phi 30$ - 1	16
49	AMVL1000-049	Bracket suction pad	04
50	AMVL1000-050	Spring $\phi 2.5$ x 70	02
51	AMVL1000-051	Tailpiece male 3/8	04
52	AMVL1000-052	Hub 350	04
53	AMVL1000-053	Seal 350	04
54	AMVL1000-054	Beam 100 x 50 x 5	01
55	AMVL1000-055	Air hose $\phi 12$	04

5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL1000-8 ASSEMBLY DIAGRAM




MECHANICAL VACUUM LIFTER Code AMVL1000-8 ASSEMBLY DIAGRAM

PARTS LIST			
No.	Code	Name Part	Qty.
01	AMVL1000-001	Main spindle	01
02	AMVL1000-002	Bolt M8 x 25	08
03	AMVL1000-003	Guide Bushing	01
04	AMVL1000-004	Bolt M10 x 50	08
05	AMVL1000-005	Lift stop	01
06	AMVL1000-006	Actuator	01
07	AMVL1000-007	Bottom piston	01
08	AMVL1000-008	Bolt M18 x 90	04
09	AMVL1000-009	Spring washer M18	10
10	AMVL1000-010	Washer M18	14
11	AMVL1000-011	Rolling	02
12	AMVL1000-012	Nut M18	06
13	AMVL1000-013	Pin $\phi 20$ - M18	01
14	AMVL1000-014	Chain $\phi 8$	02
15	AMVL1000-015	Plate 12	02
16	AMVL1000-016	Bushing M20 x 8	04
17	AMVL1000-017	Housing cover	01
18	AMVL1000-018	Bolt M6 x 25	28
19	AMVL1000-019	Check valve	01
20	AMVL1000-020	O - ring 47 - 40 - 3.5	01
21	AMVL1000-021	Piston washer	01
22	AMVL1000-022	Piston diaphragma	01
23	AMVL1000-023	Top piston	01
24	AMVL1000-024	Bolt M10 x 30	02
25	AMVL1000-025	Washer M10	02
26	AMVL1000-026	Housing	01
27	AMVL1000-027	Washer M20	02
28	AMVL1000-028	Spring washer M20	02
29	AMVL1000-029	Bolt M20 x 110	02
30	AMVL1000-030	Nut M20	02

PARTS LIST			
No.	Code	Name Part	Qty.
31	AMVL1000-031	Connector	01
32	AMVL1000-032	Vacuum gauge	01
33	AMVL1000-033	Vacuum leakage sensor	01
34	AMVL1000-034	Vacuum Guard	01
35	AMVL1000-035	Washer M6	04
36	AMVL1000-036	Bolt M6 x 12	04
37	AMVL1000-037	Bolt M5 x 16	04
38	AMVL1000-038	Handle assembly	01
39	AMVL1000-039	Beam 50 x 50 x 5	04
40	AMVL1000-040	Latch locking M10	04
41	AMVL1000-041	Bolt M12 x 185	16
42	AMVL1000-042	Latch locking M20	04
43	AMVL1000-043	Bushing $\phi 30$	64
44	AMVL1000-044	Spring $\phi 4$ x 80	32
45	AMVL1000-045	Bushing $\phi 30$ - 1	64
46	AMVL1000-046	Bracket suction pad	04
47	AMVL1000-047	Spring $\phi 2.5$ x 70	32
48	AMVL1000-048	Hub 350	08
49	AMVL1000-049	Seal 350	08
50	AMVL1000-050	Tailpiece male 3/8	08
51	AMVL1000-051	Beam 100 x 50 x 5	01
52	AMVL1000-052	Pin $\phi 14$ x 123	02
53	AMVL1000-053	Parking	02
54	AMVL1000-054	Circlip $\phi 14$	02
55	AMVL1000-055	Air hose $\phi 16$	10
56	AMVL1000-056	Cross connector 3/8	02
57	AMVL1000-057	Tee connector 3/8	02
58	AMVL1000-058	Clevis pin $\phi 20$	02
59	AMVL1000-059	Support beam	02
60	AMVL1000-060	Hair pin $\phi 5$	02

5. SPART PART LIST

MECHANICAL VACUUM LIFTER Code AMVL1000-10 ASSEMBLY DIAGRAM



MECHANICAL VACUUM LIFTER Code AMVL1000-10 ASSEMBLY DIAGRAM

PARTS LIST			
No.	Code	Name Part	Qty.
01	AMVL1000-001	Main spindle	01
02	AMVL1000-002	Bolt M8 x 25	08
03	AMVL1000-003	Guide Bushing	01
04	AMVL1000-004	Bolt M10 x 50	08
05	AMVL1000-005	Lift stop	01
06	AMVL1000-006	Actuator	01
07	AMVL1000-007	Bottom piston	01
08	AMVL1000-008	Bolt M18 x 90	04
09	AMVL1000-009	Spring washer M18	10
10	AMVL1000-010	Washer M18	14
11	AMVL1000-011	Rolling	02
12	AMVL1000-012	Nut M18	06
13	AMVL1000-013	Pin $\phi 20$ - M18	01
14	AMVL1000-014	Chain $\phi 8$	02
15	AMVL1000-015	Plate 12	02
16	AMVL1000-016	Bushing M20 x 8	04
17	AMVL1000-017	Housing cover	01
18	AMVL1000-018	Bolt M6 x 25	28
19	AMVL1000-019	Check valve	01
20	AMVL1000-020	O - ring 47 - 40 - 3.5	01
21	AMVL1000-021	Piston washer	01
22	AMVL1000-022	Piston diaphragm	01
23	AMVL1000-023	Top piston	01
24	AMVL1000-024	Bolt M10 x 30	02
25	AMVL1000-025	Washer M10	02
26	AMVL1000-026	Housing	01
27	AMVL1000-027	Washer M20	02
28	AMVL1000-028	Spring washer M20	02
29	AMVL1000-029	Bolt M20 x 110	02
30	AMVL1000-030	Nut M20	02

PARTS LIST			
No.	Code	Name Part	Qty.
31	AMVL1000-031	Connector	01
32	AMVL1000-032	Vacuum gauge	01
33	AMVL1000-033	Vacuum leakage sensor	01
34	AMVL1000-034	Vacuum Guard	01
35	AMVL1000-035	Washer M6	04
36	AMVL1000-036	Bolt M6 x 12	04
37	AMVL1000-037	Bolt M5 x 16	04
38	AMVL1000-038	Handle assembly	01
39	AMVL1000-039	Beam 50 x 50 x 5	05
40	AMVL1000-040	Latch locking M10	05
41	AMVL1000-041	Bolt M12 x 185	40
42	AMVL1000-042	Latch locking M20	05
43	AMVL1000-043	Bushing $\phi 30$	80
44	AMVL1000-044	Spring $\phi 4$ x 80	40
45	AMVL1000-045	Bushing $\phi 30$ - 1	80
46	AMVL1000-046	Bracket suction pad	05
47	AMVL1000-047	Spring $\phi 2.5$ x 70	40
48	AMVL1000-048	Hub 250	10
49	AMVL1000-049	Seal 250	10
50	AMVL1000-050	Tailpiece male 3/8	10
51	AMVL1000-051	Beam 100 x 50 x 5	01
52	AMVL1000-052	Pin $\phi 14$ x 123	02
53	AMVL1000-053	Parking	02
54	AMVL1000-054	Circlip $\phi 14$	02
55	AMVL1000-055	Air hose $\phi 16$	12
56	AMVL1000-056	Cross connector 3/8	02
57	AMVL1000-057	Tee connector 3/8	02
58	AMVL1000-058	Clevis pin $\phi 20$	02
59	AMVL1000-059	Support beam	02
60	AMVL1000-060	Hair pin $\phi 5$	02



6.1 Warranty

After receiving the goods, it is strongly recommended to the buyer to check for sure, based on the spare part list and spare drawing attached with the goods, that the spare parts has not been damaged or lost during shipment. Any damages or losses must be officially claimed to Aardwolf Industries LLC's within 8 days since the date of goods receipts.

This lifter is granted a 12-month warranty based on Aardwolf Industries LLC's warranty policy since the date of purchase.

The warranty coverage is not applicable:

Whenever the clamp is handled incorrectly during manoeuvring.

Whenever the operator fails to comply with the instructions in this booklet.

Whenever the clamp's maximum permissible capacity is exceeded. Whenever the specifications for slab thickness are not followed.

When damages are due to inadequate maintenance and inspections.

When damage is due to improper storage.

Whenever repairs were performed by the user without our permission.

Whenever non-original spare parts were used.



6.2 Disclaimer

Aardwolf Industries LLC's warranty does not cover the incorrect assembly and misuse of lifter, the lack of maintenance and repair of lifter as scheduled by the manufacturer, the operation carried out by non-competent or non-permission operator or non-original spare parts used or installed.





Vietnam

AARDWOLF VIETNAM

- 1B, An Phu, Thuan An, Binh Duong, Vietnam.
- +84 274 371 2840
- sales@aardwolf.com.au
- www.aardwolf.com.au

Korea

AARDWOLF KOREA

- 284-2 Yatap -Dong, Bundang-Ku, Seongnam-Shi, Kyuonki-Do, Korea
- +82 6487 3949
- sales@aardwolf.kr
- www.aardwolf.kr

Australia

AARDWOLF AUSTRALIA

- 2/106 Magowar Rd, Girraween NSW 2145, Australia.
- +0422 916 907
- enquiries@aardwolfaustralia.com
- www.aardwolfaustralia.com

Germany

STONE GLASS EQUIPMENT UG

- Am Gutsteich 11, 08451 Crimmitschau/ Blankenhain, Germany.
- +49 366 0811 9236
- sales@aardwolf.com.de
- www.aardwolf.com.de

India

AARDWOLF KISHANGARH

- Harmara Road, Industrial Area, Madanganj, Kishangarh, Rajasthan India / Pin no. 305801
- Tel: +91 9785016771
- Email: sales@aardwolf.co.in
- Web: www.aardwolf.co.in

AARDWOLF BENGALURU

- No: 6, Sharma Complex, 3rd Cross, Ganesha Block, Dinnur Main Road, R. T. Nagar P.O Bengaluru-560032
- +91 98451 62959/ 91 9901724600
- bengaluru@aardwolf.co.in
- www.aardwolf.co.in

