




AARDWOLF TRANSPORT FRAME 2000

OWNER'S MANUAL

PRODUCT CODE: TF-2000



CONTENTS

- ▶ GENERAL ▶ SPECIFICATIONS & FEATURES ▶ SAFETY INSTRUCTIONS ▶ INSTRUCTIONS FOR USE
- ▶ PART DRAWING & PART LIST ▶ INSPECTIONS, MAINTENANCE & REPAIR ▶ WARRANTY

Designed to store and transport sheet material such as granite, marble, engineered stone, glass, natural stone countertop, and island pieces. The Aardwolf Transport Frame Model TF2000 is the most versatile frame on the market. It is the quickest frame to assemble and disassemble, with assembly time by one man taking approximately 5 minutes. The loaded frame can be moved around a factory or work site manually by one man. The fully loaded frame can be loaded on and offloaded from trucks by forklift.



	Metric (mm-kg)	Imperial (inch-lb)
Working load limit	2500	5511
Number of wheel	4	
Strap of both sides	8	
Width of each side	268	10.6"
Net weight	182	401
Gross weight	188	414
Packaging dimensions	2000 x 1020 x 420	78.7" x 40.2" x 16.5"

- Sturdy and safe structure, designed to eliminate any risk of the slab tipping over.
 - Slabs are placed on special rubber profiles and secured with 6 locking bars together with ratchet straps to retain materials.
 - The frame features 2 hooking points to be picked up by an overhead crane.
 - Reinforced with two oblique bars for the firm and secure construction.
 - Built-in forklift receivers on all sides for lifting by forklift.
 - The base and uprights come with replaceable white rubber to prevent marking and scratches.
 - Counter-lever handle with wheels, allow the frame to be moved manually even when loaded.
 - Counter-lever handle is used to jack uploaded frame and lower support legs when wheels are not required.
 - Powder-coated finish, which ensures an aesthetic feature as well as the durability of the product.
- Note:** Support legs should always be lowered when a loaded frame is being transported on a truck.



Before operation:

- Make sure that the Transport Frame is placed on a flat and smooth surface.
- Confirm all the welded joints are free from any defects or damage, such as separation, crack, and so forth.
- Make sure that all the bolts are securely tightened.
- Use appropriate safety equipment to protect against injury.
- Check the rubber-lined ratchet straps and wheels are in the faultless conditions. If they are any damages or are defective, replace with new ones.
- Lubricate the wheels.
- If the Transport Frame combines with other attachments such as a crane or forklift truck, the user must determine whether the capacity of a crane or other hoist fits with the frame's capacity.
- Perform a load test for the frame before transporting/moving/storing the stone.

During operation:

- The materials should be restrained in a proper manner during transporting.
- Check the wheels regularly.
- The materials should be evenly loaded on both sides of the Transport Frame.
- Make sure the weight of the materials being placed is within the specified working load limit.
- Follow the steps and instructions in this operation manual.

After operation:

- Clean the Transport Frame thoroughly after each use.
- Check and lubricate wheels.
- Store in a well-ventilated place, avoid places with high heat or humidity.

Step 1: Install the wheels into the base.

Step 2: Place the materials on the frame.

Note: The materials should be evenly loaded on both sides of the frame so that it is balanced.

Step 3: Install the ratchet securing bars by setting the bottom end to the groove on the base frame, then hook on the top of frame and tighten the ratchet to restrain the slabs.

Note: Be sure to check that the working load is within the specified limit.

Step 4: Place the loaded frame on the base firmly.

Step 5: Check if all slabs are tightened on the frame before transporting and moving.

Caution: Before moving the materials confirm that the materials are neatly loaded and ratchet straps are all firm and tight.

Step 6: If the user want to move the loaded frame around the factory, they can use the handle bar to move it to the desired location.

Step 7: For transporting the loaded frame from place to place the user can use a crane or forklift truck to move.



- **With a crane:** The user can use the chain and attach to the hook with the hooking points of the frame, then lift the frame onto the truck.
- **With a forklift truck:** Slide the fork blades of the forklift truck into the pocket of the frame to lift the loaded frame until the loaded frame is fully placed on the truck. Mind the distance from forklift because of the principle of the lever, the longer the distance from the pivot the lesser the weight capacity.

Note: The user can use the Fork Extensions from Aardwolf to increase the length and strength for the forklift truck. The Fork Extensions consist of the Standard and Heavy Duty versions with different lengths and capacities.

Step 8: When finishing each cycle of the transportation, the user can remove the empty frame from the truck and can transport the next loaded frame.



TRANSPORT FRAME TF-2000
ASSEMBLY DIAGRAM



TRANSPORT FRAME TF-2000
PART LIST

CODE	POSITION	DESCRIPTION	QTY
TF2000 - 020	20	Rubber Of Load Bar	06
TF2000 - 021	21	Hexagon Bolt M6x20	12
TF2000 - 022	22	Washer Ø6	24
TF2000 - 023	23	Hexagon Nut M6	12
TF2000 - 024	24	Buckle	06
TF2000 - 025	25	Belt	06
TF2000 - 026	26	Bearing 6204	08
TF2000 - 027	27	Cantilever	01
TF2000 - 028	28	Washer Ø20	04
TF2000 - 029	29	Handhold Ø27	02
TF2000 - 030	30	Spring Washer Ø12	18
TF2000 - 031	31	Hexagon Bolt M12x40	02
TF2000 - 032	32	Spring Washer Ø14	06
TF2000 - 033	33	Plastic Cap 80x40	02
TF2000 - 034	34	Hexagon Bolt M12x100	12
TF2000 - 035	35	Cotter Pin	02
TF2000 - 036	36	Support Leg	02
TF2000 - 037	37	Pin	02

CODE	POSITION	DESCRIPTION	QTY
TF2000 - 001	1	Hexagon Bolt M14x120	06
TF2000 - 002	2	Cross Bar	01
TF2000 - 003	3	A Frame	06
TF2000 - 004	4	"C" Slot Plastic Cap 40 x 20	12
TF2000 - 005	5	Washer Ø14	12
TF2000 - 006	6	Hexagon Nut M14	06
TF2000 - 007	7	Oblique Bar	02
TF2000 - 008	8	Rubber of A Frame	12
TF2000 - 009	9	Hexagon Nut M12	18
TF2000 - 010	10	Washer Ø12	36
TF2000 - 011	11	Hexagon Bolt M12x30	04
TF2000 - 012	12	Base	01
TF2000 - 013	13	Plastic Wheel Ø150	04
TF2000 - 014	14	Circclip Ø20	04
TF2000 - 015	15	Spacing	04
TF2000 - 016	16	Pin Ø20	02
TF2000 - 017	17	Plastic Cap 40 x 40	12
TF2000 - 018	18	Rubber of Base	12
TF2000 - 019	19	Load Bar	06

When ordering, please give number of spare - part (code number) plus type of Transport Frame 2000. For

example: Transport Frame TF2000 - 001 , QTY 10

Transport Frame TF2000 - 004 , QTY 02

Updated date: March 24th , 2020

- Make a regular procedure for the frame inspection and maintenance.
- Frequency of inspection will depend upon the amount of use of the frame.
- Maintenance should be conducted in a written record, indicating inspection dates, condition of the frame on each of those dates, and any repairs made.
- Always keep necessary spare parts on hand and use only original spare parts when carrying out repairs or maintenance.
- Nuts and bolts need to be checked and tightened on a regular basis.
- Ensure that the welded joints are free from any defects or damage like separation, cracks etc.
- Make sure that all the rubber parts are in a sound condition, that they do not cause damage during operation as well as for the materials being loaded.
- Store the frame in a cool and dry place.

WARRANTY

At the time of delivery, it is necessary to check that the Transport Frame TF2000 has not been damaged during shipment. Any claims must be presented within eight days from the date of delivery. We grant one year warranty on the Transport Frame from the date of purchase (Do not include the rubber layers).

Warranty coverage is not applicable:

- The operator failed to comply with the instructions in the manual.
- The specifications are not followed.
- Damages are due to inadequate maintenance and inspections.
- Damages are due to improper storage and/or usage.
- Repairs were performed by the user without our permission.
- Non-original spare parts were used.



USA



AARDWOLF USA

- 📍 19201 S Reyes Avenue, Unit C7
Compton California, 90221
- ☎ (562) 553-6050
- ✉ leo@aardwolfusa.com
- 🌐 www.aardwolfusa.com

INDIA



AARDWOLF NORTH INDIA

- 📍 Harmara Road, Industrial area,
Madanganj, Kishangarh, Rajasthan n
India / Pin no. 305801
- ☎ Tel: +91 93584 48474
- ✉ sales@aardwolf.co.in
- 🌐 Web: www.aardwolf.co.in

AUSTRALIA



AARDWOLF AUSTRALIA

- 📍 1/5 Stanton Road,
Seven Hills NSW 2147
- ☎ +02 9838 8427
- ✉ enquiries@aardwolfaustralia.com
- 🌐 www.aardwolfaustralia.com

INDIA

AARDWOLF SOUTH INDIA

- 📍 # 9/27, Ground Floor, 5th Main Road,
Ganesha Block, Sultanpalya,
RT Nagar Post, Bengaluru-560 032
- ☎ Mob: +91 99017 24600
- ✉ bengaluru@aardwolf.co.in
- 🌐 www.aardwolf.co.in

GERMANY



STONE GLASS EQUIPMENT UG

- 📍 Am Gutstfch 11, 8451 Crimmitschau
Blankenhain, Germany.
- ☎ +49 366 0811 9236
- ✉ sales@aardwolf.com.de
- 🌐 www.aardwolf.com.de

INDIA

AARDWOLF CENTRAL INDIA

- ☎ Mob: 91 97659 06007
- ✉ mumbai@aardwolf.co.in
- 🌐 www.aardwolf.co.in

VIETNAM



AARDWOLF VIETNAM

- 📍 1B, An Phu, Thuan An,
Binh Duong, Vietnam.
- ☎ +84 274 371 2827438/39
- ✉ sales@aardwolf.com.au
- 🌐 www.aardwolf.com.au

