





FORK MOUNTED VACUUM LIFTING ATTACHMENT MODE: FMVLAV2



PARTS LIST

POS.	CODE	DESCRIPTION	QTY.
01	H002013	Seal 500x300	04
02	FMVLA-002	Straight Fitting Tube $\varnothing \frac{3}{8}$ " - Thread G $\frac{1}{8}$ "	04
03	FMVLA-003	Hub 500x300	04
04	FMVLA-004	Pin $\varnothing 13.5$, L=26mm	16
05	L004099	Helical Spring	16
06	FMVLA-006	Pad bracket	04
07	FMVLA-007	Locking pin	06
08	FMVLA-008	Bracket	03
09	FMVLA-009	Straight Fitting Tube $\varnothing \frac{3}{8}$ " - Thread G $\frac{3}{8}$ "	05
10	FMVLA-010	Straight Fitting Tube $\varnothing \frac{1}{2}$ " - Thread G $\frac{1}{2}$ "	06
11	FMVLA-011	Vertical Bar	02
12	FMVLA-012	Horizontal Bar	01
13	D022006	Red light	01
14	C009024	Tee Connector G $\frac{1}{2}$ "	03
15	FMVLA-015	Straight Fitting Tube $\varnothing \frac{1}{2}$ " - Thread G $\frac{1}{2}$ "	02
16	M007041	Electric Actuator 24V, L=300mm	01
17	FMVLA-017	Pin $\varnothing 12$	02
18	FMVLA-018	Lever	01
19	C006005	Split Pin $\varnothing 12$	02
20	D026010	Truss Head Cap Screw M4x10	25
21	D023006	Signal Light	01
22	FMVLA-022	Signal Light Bracket	01
23	T007003	Remote Control Box	01
24	C010003	Plastic Tube $\varnothing \frac{1}{2}$ " Clamp	24
25	L006022	Washer M8	01
26	B015080	Socket Head Cap Screw M6x30	04
27	FMVLA-027	Handle	02
28	C013022	Selector Switch	01
29	N030013	Power Button	01
30	D028007	Vacuum Gauge	01
31	D022005	Green Light	01
32	B012028	Battery Gauge	01
33	Q002009	Locking A19-1-2	01
34	FMVLAV2-034	Lid	01
35	C002108	Edge Trim, L=3000 mm	01
36	V001036	Check Valve	01
37	C010004	Plastic Tube $\varnothing \frac{1}{2}$ " Clamp	16
38	FMVLAV2-038	Vacuum Pump	01
39	O004025	Plastic Tube $\varnothing 6$, L=300 mm	01
40	O007003	Plastic Tube $\varnothing \frac{1}{2}$ "x5000 mm	01
41	O007002	Plastic Tube $\varnothing \frac{1}{2}$ "x3000 mm	01
42	FMVLAV2-042	Electric Box Enclosure	01
43	FMVLA-043	Electric Component Bracket	01
44	R001012	Relay_1	04
45	T001013	Nut M6	04
46	L006016	Washer M6	04
47	R001019	Relay_2	02
48	C003003	CB	01
49	L006014	Washer M4	14
50	B015055	Socket Head Cap Screw M4x10	09
51	T001032	Nut M8	08
52	C006004	Split Pin $\varnothing 6$	02
53	FMVLAV2-053	Main Frame	01
54	FMVLAV2-054	Battery Clamping	01

POS.	CODE	DESCRIPTION	QTY.
55	B015009	Socket Head Cap Screw M8x16	01
56	B015111	Socket Head Cap Screw M10x20	04
57	B015028	Countersunk Head Screw M4x10	16
58	FMVLAV2-058	Plastic Bushing	04
59	FMVLA-059	Linking Pad_1	02
60	B015171	Bolt M8x20	04
61	FMVLA-061	Linking Pad_2	02
62	FMVLA-062	Pin $\varnothing 6$	02
63	C012001	Alarm	01
64	FMVLAV2-064	Plastic Bushing Cover	04
65	D026021	Truss Head Cap Screw M6x15	12
66	O001001	Electric Socket	01
67	T001011	Nut M4	04
68	FMVLAV2-068	Battery 24V-100AH	01
69	D011010	Nipple Male Thread G $\frac{3}{8}$ " - G $\frac{1}{8}$ "	01
70	C013005	Pressure Switch	02
71	FMVLAV2-071	Solenoid Valve 24V	01
72	L005004	Filter ABF-15	01
73	D010020	Air Hose $\varnothing 6$ Male Thread G $\frac{1}{8}$ "	01
74	FMVLAV2-074	Divider	01
75	B015145	Socket Head Cap screw M20x40	04
76	FMVLAV2-076	Locking Pin	02
77	FMVLAV2-077	Locking Pad	02
78	V001015	Plugging Bolt G $\frac{1}{2}$ "	01
79	B015038	Countersunk Head Screw M8x10	04