


AARDWOLF SLAB LIFTER - AL30 ASSEMBLY DIAGRAM



POSITION	DESCRIPTION	CODE	QTY.
1	Hexagon Socket Countersunk Head Screw M12x40	B015050	2
2	Hexagon Socket Countersunk Head Screw M16x50	B015051	2
3	Back Plate	AL30-003	1
5	Tapping Screw M4x15	D026033	8
7	Center Sliding Plate	AL30-007	1
8	Extension Spring	L004011	4
9	Inner Pressure Wheel	AL30-009	1
10	Brass Washer Ø20	L006057	6
11	Outer Pressure Wheel	AL30-011	2
12	Shaft	AL30-012	1
13	Circlip Ø20	P001009	2
15	Camplate	AL30-015	1
16	Rubber Pieces	C002029	2
17	Lanyard	AL30-017	1
18	Socket Head Cap Screw M5x60	B015072	1
19	Locking Latch	AL30-019	1
20	Nylon Nut M5	T001028	1
21	Torsion Spring	L004018	1
22	Washer Ø5	L006015	2
23	Shackle	D020018	1
24	Lifting Pin	AL30-024	1