


AARDWOLF SLAB LIFTER - AL40A ASSEMBLY DIAGRAM



POSITION	DESCRIPTION	CODE	QTY.
1	Hexagon Socket Countersunk Head Screw M12x40	B015050	2
2	Hexagon Socket Countersunk Head Screw M16x50	B015051	2
3	Back Plate	AL50-003	1
5	Tapping Screw M4x15	D026033	8
7	Center Sliding Plate	AL50-007	1
8	Bottom Extension Spring	L004007	4
9	Inner Pressure Wheel	AL50-009	1
10	Brass Washer Ø20	L006057	6
11	Outer Pressure Wheel	AL50-011	2
12	Shaft	AL30-012	1
13	Circlip Ø20	P001009	2
15	Camplate	AL40A-015	1
16	Rubber Pieces	C002029	2
21	Compression Spring	L004012	1
22	Top Extension Spring	L004009	2
23	Shackle	D020018	1
24	Spring Cap	AL30A-023	1
26	Lifting Pin	AL50A-026	1
27	Locking Pin	AL30A-027	1
28	Hexagon Socket Set Screw M8x16	B015021	2
29	Plastic Cap	AL30A-029	1
30	Circlips Ø10	P001013	2
31	Washer Ø10	L006025	2
32	Roller Support	AL40-032	2
33	Plastic Roller	AL40-033	2
34	Roller Base	AL40-034	2
35	Hexagon Socket Countersunk Head Screws M6x10	B015031	2