


AARDWOLF SLAB LIFTER - AL60 ASSEMBLY DIAGRAM



POSITION	DESCRIPTION	CODE	QTY.
1	Hexagon Socket Countersunk Head Screw M12x40	B015050	2
2	Hexagon Socket Countersunk Head Screw M20x60	B015052	2
3	Back Plate	AL60-003	1
5	Tapping Screw M4x15	D026033	8
7	Center Sliding Plate	AL60-007	1
8	Bottom Extension Spring	L004008	2
9	Inner Pressure Wheel	AL60-009	1
10	Brass Washer Ø25	L006059	6
11	Outer Pressure Wheel	AL60-011	2
12	Shaft	AL60-012	1
13	Circlip Ø25	P001020	2
15	Camplate	AL60-015	1
16	Rubber Pieces	C002029	2
17	Lanyard	AL30-017	1
18	Socket Head Cap Screw M5x60	B015072	1
19	Locking Latch	AL30-019	1
20	Nylon Nut M5	T001028	1
21	Torsion Spring	L004018	1
22	Top Extension Spring	L004010	2
23	Shackle	D020018	1
24	Lifting Pin	AL60-024	1
25	Washer Ø5	L006015	2