


## AARDWOLF SLAB LIFTER - AL60A ASSEMBLY DIAGRAM



| POSITION | DESCRIPTION                                  | CODE      | QTY. |
|----------|----------------------------------------------|-----------|------|
| 1        | Hexagon Socket Countersunk Head Screw M12x40 | B015050   | 2    |
| 2        | Hexagon Socket Countersunk Head Screw M20x60 | B015052   | 2    |
| 3        | Back Plate                                   | AL60-003  | 1    |
| 5        | Tapping Screw M4x15                          | D026033   | 8    |
| 7        | Center Sliding Plate                         | AL60-007  | 1    |
| 8        | Bottom Extension Spring                      | L004008   | 2    |
| 9        | Inner Pressure Wheel                         | AL60-009  | 1    |
| 10       | Brass Washer Ø25                             | L006059   | 6    |
| 11       | Outer Pressure Wheel                         | AL60-011  | 2    |
| 12       | Shaft                                        | AL60-012  | 1    |
| 13       | Circlip Ø25                                  | P001020   | 2    |
| 15       | Camplate                                     | AL60A-015 | 1    |
| 16       | Rubber Pieces                                | C002029   | 2    |
| 21       | Compression Spring                           | L004012   | 1    |
| 22       | Top Extension Spring                         | L004010   | 2    |
| 23       | Shackle                                      | D020018   | 1    |
| 24       | Spring Cap                                   | AL30A-023 | 1    |
| 26       | Lifting Pin                                  | AL60A-026 | 1    |
| 27       | Locking Pin                                  | AL30A-027 | 1    |
| 28       | Hexagon Socket Set Screw M8x16               | B015021   | 2    |
| 29       | Plastic Cap                                  | AL30A-029 | 1    |