


AARDWOLF SLAB LIFTER - AL75A ASSEMBLY DIAGRAM



POSITION	DESCRIPTION	CODE	QTY.
1	Hexagon Socket Countersunk Head Screw M12x40	B015050	2
2	Hexagon Socket Countersunk Head Screw M20x60	B015052	2
3	Back Plate	AL60-003	1
5	Tapping Screw M4x15	D026033	8
7	Center Sliding Plate	AL60-007	1
8	Bottom Extension Spring	L004008	2
9	Inner Pressure Wheel	AL60-009	1
10	Brass Washer Ø25	L006059	6
11	Outer Pressure Wheel	AL60-011	2
12	Shaft	AL60-012	1
13	Circlip Ø25	P001020	2
15	Camplate	AL75A-015	1
16	Rubber Pieces	C002029	2
21	Compression Spring	L004012	1
22	Top Extension Spring	L004010	2
23	Shackle	D020018	1
24	Spring Cap	AL30A-023	1
26	Lifting Pin	AL60A-026	1
27	Locking Pin	AL30A-027	1
28	Hexagon Socket Set Screw M8x16	B015021	2
29	Plastic Cap	AL30A-029	1