



ASSEMBLY DIAGRAM STACKING RACK-1500 (Mod: ASTR01)



PARTS LIST

CODE	POSITION	DESCRIPTION	QTY
ASTR01 - 001	1	Hexagon Bolt M10x30	20
ASTR01 - 002	2	Support Bar 1	02
ASTR01 - 003	3	Support Bar 2	04
ASTR01 - 004	4	Cross Bar	02
ASTR01 - 005	5	Rubber TS-50 727mm	02
ASTR01 - 006	6	Left Body	01
ASTR01 - 007	7	Hexagon Bolt M10x80	12
ASTR01 - 008	8	Rubber TS-40 708mm	30
ASTR01 - 009	9	Oblique Bar	02
ASTR01 - 010	10	Rubber TS-50 569mm	24
ASTR01 - 011	11	Washer Ø10	64
ASTR01 - 012	12	Support Bar 3	04
ASTR01 - 013	13	Right Body	01
ASTR01 - 014	14	Spring Washer Ø10	32
ASTR01 - 015	15	Hexagon Nut M10	32

When ordering, please give number of spare - part (code number) plus type of Stacking Rack - 1500.
 For example: Stacking Rack ASTR01 - 001 , QTY 10
 Stacking Rack ASTR01 - 004 , QTY 02