




PARTS LIST			
No.	Code	Parts Name	Qty.
1	STH5L01	Wood Table Surface	1
2	STH5L02	Socket Head Bolt M8 x 30	1
3	STH5L03	Steel Plate	1
4	STH5L04	Screw 6.3x1.8 x 25	12
5	STH5L05	Five Legs Frame	1
6	STH5L06	Bolt M10 x 35	20
7	STH5L07	Plain Washer M10	40
8	STH5L08	Spring Washer M10	20
9	STH5L09	Nut M10	20
10	STH5L10	Hydraulic Foot-Pump	1
11	STH5L11	Caster Wheel	5