



ASSEMBLY DIAGRAM MITER CLAMP - VACUUM ASSISTED (Code: ABMC)



PARTS LIST

No.	Code	Part Number	Qty.
01	ABMC-001	Single Pad	02
02	ABMC-002	Corner ball valve $\phi 6 - 1/4$	02
03	ABMC-003	Sponge seal 7 x 10	04
04	ABMC-004	Guide axle	06
05	ABMC-005	Cover plate	06
06	ABMC-006	Bolt M4 x 10	24
07	ABMC-007	Thread Axle	06
08	ABMC-008	Slide Button	06
09	ABMC-009	Spring $\phi 0.5 \times 10$	06
10	ABMC-010	Bolt M4 x 5	06
11	ABMC-011	Steel Piece	06

No.	Code	Part Number	Qty.
12	ABMC-012	Latch locking M10	06
13	ABMC-013	Bolt M6 x 20	12
14	ABMC-014	Rest Arm	06
15	ABMC-015	Washer M6	06
16	ABMC-016	Nut M6	06
17	ABMC-017	Spiral hose $\phi 6$	04
18	ABMC-018	Ball valve - 1/4	02
19	ABMC-019	Air divider	01
20	ABMC-020	Quick air connection 1/8	01
21	ABMC-021	Electric vacuum box	01
22	ABMC-022	Corner Pad	02
23	ABMC-023	Tee Valve connection $\phi 6$	02