




PARTS LIST

Position	Code	Description	Qty.
1	AGL32 - 01	Lug links	01
2	AGL32 - 02	Lifting rear	01
3	AGL32 - 03	Lifting front	01
4	AGL32 - 04	Countersunk head socket screw M8 x 30	05
5	AGL32 - 05	Top pin guide (*)	01
6	AGL32 - 06	Bottom pin guide (*)	01
7	AGL32 - 07	Roller B (*)	02
8	AGL32 - 08	Roller Bearing HK2016	02
9	AGL32 - 09	Shaft B (*)	02
10	AGL32 - 10	Pan head screw M3 x 10	02
11	AGL32 - 11	Cover	02
12	AGL32 - 12	Hex. nut M10	02
13	AGL32 - 13	Spring washer Ø 10	02
14A	AGL32 - 14A	Main body front	01
14B	AGL32 - 14B	Main body rear	01
15	AGL32 - 15	Pin M6 (*)	02
16	AGL32 - 16	Extension spring Ø5.6 - 40 (*)	02
17	AGL32 - 17	Locking latch arm (*)	01
18	AGL32 - 18	Plate (*)	01
19	AGL32 - 19	Brass Washer Ø10	01
20	AGL32 - 20	Circlip Ø10	01
21	AGL32 - 21	Cam Locking latch (*)	01
22	AGL32 - 22	Hexgon domed Cap nut M16	02
23	AGL32 - 23	Spring washer Ø 16	02
24	AGL32 - 24	Hex. nut M6	02
25	AGL32 - 25	Spring washer Ø 6	02
26	AGL32 - 26	Arm	02
27	AGL32 - 27	Extension spring	01

Position	Code	Description	Qty.
28	AGL32 - 28	Torsion spring	02
29	AGL32 - 29	Spacing B (*)	02
30	AGL32 - 30	Roller A (*)	02
31	AGL32 - 31	Spacing A (*)	02
32	AGL32 - 32	Hexagon socke head cap screw M10 x 55	02
33	AGL32 - 33	Hexagon socke head cap screw M6 x 50	02
34	AGL32 - 34	Hexagon socke head cap screw M16 x 60	02
35	AGL32 - 35	Stop guide	01
36	AGL32 - 36	Jaw shaft (*)	02
37	AGL32 - 37	Jaw	02
38	AGL32 - 38	Set Screw M6 x 10	04
39	AGL32 - 39	Wheel Shaft	08
40	AGL32 - 40	Wheel Ø 75	08
41	AGL32 - 41	Washer Ø 14	16
42	AGL32 - 42	Circlip Ø 14	16
43	AGL32 - 43	Recessed pan head screw M6x12	01
44	AGL32 - 44	Hexagon socke head cap screw M6 x 20	12
45	AGL32 - 45	Locking stop guide (*)	01
46	AGL32 - 46	Locking shaft (*)	01
47	AGL32 - 47	Ball pin (*)	01
48	AGL32 - 48	Compression spring (*)	01
49	AGL32 - 49	Set Screw M10 x 10	01
50	AGL32 - 50	Compression spring	02
51	AGL32 - 51	Steel ball Ø10	02
52	AGL32 - 52	Handle base	02
53	AGL32 - 53	Plastic handle	02
54	AGL32 - 54	Slide bar	02

(*) Part universal for all Aardwolf glass lifter models.

When ordering spare parts, please show the codes of parts and quantities on your purchase order.

For example: part code: AGL22-17 , QTY: 10

Update date: 17/01/2018