



MECHANICAL VACUUM LIFTER

Code AMVL250-2

ASSEMBLY DIAGRAM

PARTS LIST

No.	Code	Name Part	Qty.
01	AMVL250-001	Bow Shackles	01
02	AMVL250-002	Main spindle	01
03	AMVL250-003	Actuator shaft	01
04	AMVL250-004	Actuator pin $\varnothing 4$	02
05	AMVL250-005	Actuator lock	01
06	AMVL250-006	Actuator plate	01
07	AMVL250-007	Screw M6 x 12	01
08	AMVL250-008	Actuator rubber cover	01
09	AMVL250-009	O-ring 60 x 72 x 6	01
10	AMVL250-010	Bolt M6 x 25	12
11	AMVL250-011	Top Housing	01
12	AMVL250-012	Bolt M6 x110	08
13	AMVL250-013	Top piston	01
14	AMVL250-014	Piston diaphragma	01
15	AMVL250-015	Middle piston	01
16	AMVL250-016	Bolt M10 x 50	08
17	AMVL250-017	Lift stop	02
18	AMVL250-018	O-ring 165 x 172 x 3.5	01
19	AMVL250-019	Bottom piston	01

PARTS LIST

No.	Code	Name Part	Qty.
20	AMVL250-020	Bolt M10 x 20	02
21	AMVL250-021	Washer M10	02
22	AMVL250-022	Housing	01
23	AMVL250-023	Nut M8	04
24	AMVL250-024	Washer M8	12
25	AMVL250-025	Gauge guard	01
26	AMVL250-026	Bolt M5 x 16	04
27	AMVL250-027	Tailpiece male 1/4	02
28	AMVL250-028	Shaft Beam 60 x 60 x 1300	01
29	AMVL250-029	Plastic plate	02
30	AMVL250-030	U $\varnothing 8$ taro M8	04
31	AMVL250-031	Latch locking M6	04
32	AMVL250-032	Bolt M8 x 25	08
33	AMVL250-033	Air hose $\varnothing 6$	02
34	AMVL250-034	Tailpiece male 1/4	02
35	AMVL250-035	Bracket beam 60 x 60	02
36	AMVL250-036	Hub 300	02
37	AMVL250-037	Seal 300	02
37	AMVL250-037	Handle assembly	01