



MECHANICAL VACUUM LIFTER

Code AMVL600-2

ASSEMBLY DIAGRAM

PARTS LIST			
No.	Code	Name Part	Qty.
1	AMVL600 - 001	Bow shackle	01
2	AMVL600 - 002	Main spindle	01
3	AMVL600 - 003	Actuator	01
4	AMVL600 - 004	Eye bolt M8	02
5	AMVL600 - 005	Valve locking	01
6	AMVL600 - 006	O-ring 40 x 47 x 3.5	01
7	AMVL600 - 007	Bolt G3/4	01
8	AMVL600 - 008	O-ring 50 x 60 x 5	01
9	AMVL600 - 009	Bolt M6 x 20	46
10	AMVL600 - 010	Top housing	01
11	AMVL600 - 011	Piston diaphragm	01
12	AMVL600 - 012	Piston small	01
13	AMVL600 - 013	Piston ring	01
14	AMVL600 - 014	Bolt M10 x 65	08
15	AMVL600 - 015	Lift stop	01
16	AMVL600 - 016	Bottom piston	01
17	AMVL600 - 017	Housing	01
18	AMVL600 - 018	Washer M10	16
19	AMVL600 - 019	Bolt M10 x 35	06
20	AMVL600 - 020	Box cover	01
21	AMVL600 - 021	Bolt M3 x 12	04
22	AMVL600 - 022	Nut M10	08
23	AMVL600 - 023	Filter pad	01
24	AMVL600 - 024	Filter 3/4	01
25	AMVL600 - 025	Main bar 1300	01
26	AMVL600 - 026	Air hose Ø13	06
27	AMVL600 - 027	Connection 1/4 x 2	01
28	AMVL600 - 028	Bolt M12 x 35	08
29	AMVL600 - 029	Washer M12	08
30	AMVL600 - 030	Connection 1/4	05
31	AMVL600 - 031	Suction bracket	02
32	AMVL600 - 032	Latch locking M6	04
33	AMVL600 - 033	Hub 350	04
34	AMVL600 - 034	Seal 350	02
35	AMVL600 - 035	Parking	02
36	AMVL600 - 036	U bolt M10	02
37	AMVL600 - 037	Support plate	02
38	AMVL600 - 038	Handle assembly	01