



MECHANICAL VACUUM LIFTER
Code AMVL600-4 IN LINE
ASSEMBLY DIAGRAM

PARTS LIST			
No.	Code	Name Part	Qty.
1	AMVL600 - 001	Bow shackle	01
2	AMVL600 - 002	Main spindle	01
3	AMVL600 - 003	Actuator	01
4	AMVL600 - 004	Eye bolt M8	02
5	AMVL600 - 005	Valve locking	01
6	AMVL600 - 006	O-ring 40 x 47 x 3.5	01
7	AMVL600 - 007	Bolt G3/4	01
8	AMVL600 - 008	O-ring 50 x 60 x 5	01
9	AMVL600 - 009	Bolt M6 x 20	34
10	AMVL600 - 010	Top housing	01
11	AMVL600 - 011	Piston diaphragma	01
12	AMVL600 - 012	Piston small	01
13	AMVL600 - 013	Piston ring	01
14	AMVL600 - 014	Bolt M10 x 65	08
15	AMVL600 - 015	Lift stop	01
16	AMVL600 - 016	Bottom piston	01
17	AMVL600 - 017	Housing	01
18	AMVL600 - 018	Bolt M10 x 25	02
19	AMVL600 - 019	Washer M10	02
20	AMVL600 - 020	Box cover	01
21	AMVL600 - 021	Bolt M3 x 12	04
22	AMVL600 - 022	Nut M10	08
23	AMVL600 - 023	Filter pad	01
24	AMVL600 - 024	Filter	01
25	AMVL600 - 025	Main bar 2200	01
26	AMVL600 - 026	Air hose Ø10	06
27	AMVL600 - 027	Tee connection 1/4	01
28	AMVL600 - 028	Connection 1/4 x 3	01
29	AMVL600 - 029	Bolt M12 x 35	22
30	AMVL600 - 030	Washer M12	16
31	AMVL600 - 031	Bracket	04
32	AMVL600 - 032	Latch locking M6	08
33	AMVL600 - 033	Hub 300	04
34	AMVL600 - 034	Seal 300	04
35	AMVL600 - 035	Connection 1/4	06
36	AMVL600 - 036	Parking	02
37	AMVL600 - 037	U bolt M10	04
38	AMVL600 - 038	Support plate	02
39	AMVL600 - 039	Handle assembly	01