


ANCHOR MACHINE



PARTLIST

CODE	POSITION	DESCRIPTION	QTY
	1	Nut cap	2
	2	O-ring 10-1.8	2
	3	Spring	2
	4	Brass washer	2
	5	O-ring 8-1.8	2
	6	Teflon washer	4
	7	Socket counter hear crew M4x10	4
	8	Lock valve	2
	9	Brass plate	2
	10	Pin cotter Ø3-10	2
	11	Socket counter hear crew M2.5x5	4
	12	Pin valve	2
	13	O-ring Ø4.5-1.8	4
	14	Male fitting 1/4 tube 10	1
	15	O-ring Ø8.5-1.8	1
	16	Venturi pin	1
	17	O-ring Ø6-1.8	1
	18	Main valve	1
	19	The hand	1
	20	Socket counter hear crew M6x10	4
	21	Socket set screw cone point M12x40	2
	22	Nut M12	2
	23	Point nut M10	2
	24	Rotary base	1
	25	O-ring 6-1.8	2
	26	Vacuum base	1
	27	Hand pat	2
	28	Silencer	1