




PARTS LIST

No.	Code	Name	Qty.
1	AVGLP2-AR-01	Handle - Vacuum (AVLP1-250Kg) Subassembly	01
2	AVGLP2-AR-02	Cylinder SC 100 x 300	01
3	AVGLP2-AR-03	Pneumatic Speed Control Valve	04
4	AVGLP2AR-04	Spring Washer M10	03
5	AVGLP2-AR-05	Hexagon Socket Head Cap Screw M10x40	02
6	AVGLP2-AR-06	Body	01
7	AVGLP2-AR-07	Horizontal Plain Bearing	04
8	AVGLP2-AR-08	Cover	01
9	AVGLP2-AR-09	Blocking Nut	01
10	AVGLP2-AR-10	Hexagon Socket Head Cap Screw M8x20	01
11	AVGLP2-AR-11	Coupling Joint 3/8"	01
12	AVGLP2-AR-12	Spring Washer ϕ 18	02
13	AVGLP2-AR-13	Bearing Support	01
14	AVGLP2-AR-14	Cylinder SC 80 x 175	01
15	AVGLP2-AR-15	Extension Bar	02
16	AVGLP2-AR-16	Bolt M6x10	01
17	AVGLP2-AR-17	Plain Bearing	02
18	AVGLP2-AR-18	Hexagon Nut M18	01
19	AVGLP2-AR-19	Hexagon Socket Head Cap Screw M18x120	02
20	AVGLP2-AR-20	Pin	03
21	AVGLP2-AR-21	Horizontal Hanging Bar	02
22	AVGLP2-AR-22	Cotter Pin	02
23	AVGLP2-AR-23	Shaft	01
24	AVGLP2-AR-24	Spring Washer ϕ 8	02
25	AVGLP2-AR-25	Hexagon Bolt M8x80	02
26	AVGLP2-AR-26	Washer ϕ 10	02
27	AVGLP2-AR-27	Hexagon Nut M10	01
28	AVGLP2-AR-28	Vacuum cup ϕ 300	02