


AVGLP4-400L - VACUUM LIFTER ASSEMBLY DIAGRAM



PARTS LIST

POSITION	CODE	DESCRIPTION	QTY.
1	AVGLP4-400L-001	VACUUM SWITCH	1
2	AVGLP4-400L-002	Y CONNECTION Ø6	1
3	AVGLP4-400L-003	COVER	1
4	AVGLP4-400L-004	BATTERY BASE	1
5	AVGLP4-400L-005	FLAT COUNTERSUNK HEAD M3x12	4
6	AVGLP4-400L-006	PRESSURE CONTROLLER	1
7	AVGLP4-400L-007	CONNECT MALE TUBE 1/4	1
8	AVGLP4-400L-008	NOZZLE	1
9	AVGLP4-400L-009	O-RING SEAL Ø12.8	1
10	AVGLP4-400L-010	VENTURI PUMP	1
11	AVGLP4-400L-011	PLASTIC SILENCER	1
12	AVGLP4-400L-012	L-CONNECT MALE Ø10x3/8	2
13	AVGLP4-400L-013	FILTER	1
14	AVGLP4-400L-014	BATTERY	1
15	AVGLP4-400L-015	TAILPIECE MALE 1/4	4
16	AVGLP4-400L-016	COVER BOLT 1/4	6
17	AVGLP4-400L-017	DELIVER - A	2
18	AVGLP4-400L-018	AIR OUTER VALVE 1/4	1
19	AVGLP4-400L-019	COLLAR Ø16	12
20	AVGLP4-400L-020	COMPRESSED AIR HOSE Ø10	1
21	AVGLP4-400L-021	TAILPIECE - MALE Ø12x1/4	4
22	AVGLP4-400L-022	AIR HOSE Ø16-B	1
23	AVGLP4-400L-023	I - CONNECTOR TUBE Ø10x1/4	1
24	AVGLP4-400L-024	HEXAGON SOCKET HEAD CAP SCREW M5x30	2
25	AVGLP4-400L-025	ELBOW MALE TUBE Ø6x1/8	2
26	AVGLP4-400L-026	MACHINE SCREW M5x10	2
27	AVGLP4-400L-027	MACHINE SCREW M4x10	3
28	AVGLP4-400L-028	VACUUM GAUGE	1
29	AVGLP4-400L-029	WARNING HORN	1
30	AVGLP4-400L-030	AIR REGULATION GAUGE	1
31	AVGLP4-400L-031	NUT M4	4
32	AVGLP4-400L-032	ELBOW FEMALE TUBE Ø6x1/4	1
33	AVGLP4-400L-033	VACUUM TANK	1
34	AVGLP4-400L-034	CHECK VALVE	1
35	AVGLP4-400L-035	BUSH	1
36	AVGLP4-400L-036	DELIVER - B	1
37	AVGLP4-400L-037	QUICK CONNECTOR 1/8 - Ø4	1
38	AVGLP4-400L-038	ELBOW MALE TUBE Ø4x1/8	1
39	AVGLP4-400L-039	PIN Ø20x55	4
40	AVGLP4-400L-040	CIRCLIP Ø20	8
41	AVGLP4-400L-041	ELBOW MALE TUBE Ø10x1/2	2
42	AVGLP4-400L-042	AIR HOSE Ø10x100	2
43	AVGLP4-400L-043	TEE FEMALE TUBE FIT Ø10x1/2	2
44	AVGLP4-400L-044	HEXAGON SOCKET HEAD CAP SCREW M10x40	2
45	AVGLP4-400L-045	WASHER Ø10	2
46	AVGLP4-400L-046	PLASTIC BUSH	2
47	AVGLP4-400L-047	FLANGE	4
48	AVGLP4-400L-048	COUNTERSUNK SCREW M4x12	16
49	AVGLP4-400L-049	CROSS BAR	1
50	AVGLP4-400L-050	PLASTIC COVER	2
51	AVGLP4-400L-051	HEXAGON SOCKET HEAD CAP SCREW M10x20	4
52	AVGLP4-400L-052	CYLINDER SC80x200	2
53	AVGLP4-400L-053	HANDLE (LEFT)	1
54	AVGLP4-400L-054	HANDLE (RIGHT)	1
55	AVGLP4-400L-055	HOLE COVER - A	12
56	AVGLP4-400L-056	TUBE COVER	2
57	AVGLP4-400L-057	WASHER Ø20x3.5	4
58	AVGLP4-400L-058	ARM (RIGHT)	1
59	AVGLP4-400L-059	ARM (LEFT)	1
60	AVGLP4-400L-060	COUNTERSUNK FLAT HEAD SCREW M4x20	4
61	AVGLP4-400L-061	HEXAGON SOCKET HEAD CAP SCREW M8x35	16
62	AVGLP4-400L-062	BRACKET	4
63	AVGLP4-400L-063	TAILPIE G1/4xØ12	4
64	AVGLP4-400L-064	BUSHING	16
65	AVGLP4-400L-065	CONE SPRING	16
66	AVGLP4-400L-066	RUBBER SUCTION CUP	4
68	AVGLP4-400L-068	LATCH LOCKING	4
69	AVGLP4-400L-069	WASHER Ø6	2
70	AVGLP4-400L-070	HEXAGON SOCKET HEAD CAP SCREW M6x55	2
71	AVGLP4-400L-071	NYLON NUT M6	2
72	AVGLP4-400L-072	RUBBER HANDLE	2
73	AVGLP4-400L-073	PUSH BUTTON	2
74	AVGLP4-400L-074	HANDLE ASSEMBLY	1
75	AVGLP4-400L-075	ROUND HEAD MACHINE SCREW M4x10	6
76	AVGLP4-400L-076	PENDANT CONTROL BRACKET	1
77	AVGLP4-400L-077	GUIDE ROD RIGHT	1
78	AVGLP4-400L-078	GUIDE ROD LEFT	1
79	AVGLP4-400L-079	HEXAGON SOCKET HEAD CAP SCREW M6x40	4
80	AVGLP4-400L-080	HOLE COVER - B	4
81	AVGLP4-400L-081	SHAFT	2
82	AVGLP4-400L-082	L-CONNECTOR MALE Ø10 - G1/4	3
83	AVGLP4-400L-083	AIR HOSE Ø16	4
84	AVGLP4-400L-084	I-CONNECTOR MALE Ø10 - G1/4	1
85	AVGLP4-400L-085	HANDLE CONNECTOR	2
86	AVGLP4-400L-086	O-RING OD22.36 - Ø2.62	4
87	AVGLP4-400L-087	SLIDE VALVE	1
88	AVGLP4-400L-088	HEXAGON SOCKET HEAD CAP SCREW M4x14	12
89	AVGLP4-400L-089	O-RING OD13.56 - Ø1.78	5
90	AVGLP4-400L-090	O-RING OD13 - Ø1.9	36
91	AVGLP4-400L-091	O-RING OD9.5 - Ø1.7	5
92	AVGLP4-400L-092	COVER SCREW	2
93	AVGLP4-400L-093	CONNECTOR MALE 1/4	1
94	AVGLP4-400L-094	AIR CONNECTOR	1
95	AVGLP4-400L-095	SPIRAL HOSE	1
96	AVGLP4-400L-096	BODY	1
97	AVGLP4-400L-097	SPECIAL BOLT	2
98	AVGLP4-400L-098	LEFT CONNECTION BOX	1
99	AVGLP4-400L-099	WIND NUT M6	1
100	AVGLP4-400L-100	O-RING OD17.5 - Ø2.5	5
101	AVGLP4-400L-101	L-CONNECTOR Ø6xG1/8	2
102	AVGLP4-400L-102	HEXAGON SOCKET HEAD CAP SCREW M4x30	3
103	AVGLP4-400L-103	HANDLE VALVE STNC TG3521B-08C	1
104	AVGLP4-400L-104	RIGHT CONNECTOR BOX	1
105	AVGLP4-400L-105	PRESSURE CONTROLLER	2
106	AVGLP4-400L-106	LOCKING NUT	2
107	AVGLP4-400L-107	O-RING OD6.56 - Ø1.78	2
108	AVGLP4-400L-108	ADJUSTABLE KNOB	2
109	AVGLP4-400L-109	HEXAGON SOCKET HEAD CAP SCREW M4x16	2