




ELECTRIC JOINT SETTER Model EOSS ASSEMBLY DIAGRAM



PARTS LIST

No.	Code	Part Number	Qty.
01	EOSS - 001	Plate with exhaust valve	02
02	EOSS - 002	Pin $\phi 2 \times 43$	02
03	EOSS - 003	Spring	02
04	EOSS - 004	Exhaust valve	02
05	EOSS - 005	Bearing holder	04
06	EOSS - 006	Long pad	04
07	EOSS - 007	Bolt M5 x 25	16
08	EOSS - 008	Short pad	04
09	EOSS - 009	Quick connector $\phi 6-1/8''$	06
10	EOSS - 010	Main axle	02
11	EOSS - 011	Horizontal pad	02
12	EOSS - 012	Level adjust pad	04
13	EOSS - 013	Hose $\phi 6$	02
14	EOSS - 014	Plastic piece	04
15	EOSS - 015	Bolt M4x 8	04
16	EOSS - 016	Plate connect vacuum	02
17	EOSS - 017	Seal $\phi 2.5$	04
18	EOSS - 018	Sponge rubber seal foam	04
19	EOSS - 019	Circlip $\phi 15$	04
20	EOSS - 020	Electric vacuum pump	01
21	EOSS - 021	Spiral Hose $\phi 6$	02
22	EOSS - 022	Quick Coupling $1/8''$	01
23	EOSS - 023	Quick connector $\phi 6-1/4''$	02
24	EOSS - 024	Ball Valve $1/4''$	02
25	EOSS - 025	dive $1/8''-1/8''-1/4''$	01

