



ASSEMBLY DIAGRAM
HAND VACUUM - CUP LIFTER
(Mod. HVC01)



PARTS LIST

CODE	POS.	Name	Qty.
HVC01-01	1	Vacuum Cup ϕ 220	01
HVC01-02	2	Hexagon Socket Button Head Screw M4x15	02
HVC01-03	3	Release Lever	01
HVC01-04	4	Release Valve	01
HVC01-05	5	Compressor Spring 1	01
HVC01-06	6	Pin	01
HVC01-07	7	Cover	01
HVC01-08	8	Vavle Base	01
HVC01-09	9	Left Hanging	01
HVC01-10	10	Hexagon Socket Countersunk Head Screw M6x10	04
HVC01-11	11	Oring ϕ 27x3	01
HVC01-12	12	Oring ϕ 8.5x2	01
HVC01-13	13	Rubber Diaphragm	01
HVC01-14	14	Locking Piece	01
HVC01-15	15	Cylinder With Handle	01
HVC01-16	16	Right Hanging	01
HVC01-17	17	Piston	01
HVC01-18	18	Air Seal	01
HVC01-19	19	Pushing Handle	01
HVC01-20	20	Compressor Spring 2	01
HVC01-21	21	Pump Handle	01