





ASSEMBLY DIAGRAM
HORIZONTAL STONE LIFTING CLAMP 2010 - 4 Tons
(Mod. AHLC2010-4T)



PARTS LIST

CODE	POS.	DESCRIPTION	QTY
AHLC2010-4T - 001	1	Hook	01
AHLC2010-4T - 002	2	Hexagon Socket Head Cap Screw M30x230	01
AHLC2010-4T - 003	3	Hexagon Socket Head Cap Screw M30x200	04
AHLC2010-4T - 004	4	Right Upper Arm	02
AHLC2010-4T - 005	5	Hexagon Nylon Nut M8	02
AHLC2010-4T - 006	6	Washer Ø8	02
AHLC2010-4T - 007	7	Socket Head Cap Screw M8x40	02
AHLC2010-4T - 008	8	Left Upper Arm	01
AHLC2010-4T - 009	9	Countersunk Screw M8x30	04
AHLC2010-4T - 010	10	Locking Body	01
AHLC2010-4T - 011	11	Washer Ø30	16
AHLC2010-4T - 012	12	Hexagon Nylon Nut M30	06
AHLC2010-4T - 013	13	Right Lower Arm	01
AHLC2010-4T - 014	14	Left Lower Arm 1	01
AHLC2010-4T - 015	15	Left Lower Arm 2	01
AHLC2010-4T - 016	16	Hexagon Socket Head Cap Screw M30x170	01
AHLC2010-4T - 017	17	Locking Base	01

CODE	POS.	DESCRIPTION	QTY
AHLC2010-4T - 018	18	Cross Bar	01
AHLC2010-4T - 019	19	Circlips Ø45	08
AHLC2010-4T - 020	20	Slide Bar	02
AHLC2010-4T - 021	21	Left Arm	01
AHLC2010-4T - 022	22	Plastic Cap 150x100x6	02
AHLC2010-4T - 023	23	Pin 4	02
AHLC2010-4T - 024	24	Pu Pad	02
AHLC2010-4T - 025	25	Pin 5	02
AHLC2010-4T - 026	26	Nylon Nut M10	08
AHLC2010-4T - 027	27	Jaw	02
AHLC2010-4T - 028	28	Washer Ø10	08
AHLC2010-4T - 029	29	Circlips Ø20	02
AHLC2010-4T - 030	30	Bush	04
AHLC2010-4T - 031	31	Right Arm	01
AHLC2010-4T - 032	32	Steel Ball	06
AHLC2010-4T - 033	33	Cotter Pin	06

When ordering, please give number of spare - part (code number) plus type of Horizontal Stone Lifting Clamp 2010 - 4 Tons.

For example: Horizontal Stone Lifting Clamp AHLC2010-4T - 001 , QTY 10

Horizontal Stone Lifting Clamp AHLC2010-4T - 004 , QTY 02

Updated date: June 22th, 2020