



ASSEMBLY DIAGRAM

TWISTER

(Mod: MSS)



PARTS LIST

CODE	POSITION	DESCRIPTION	QTY
MSS-001	1	Cover	01
MSS-002	2	Shut on/off	01
MSS-003	3	Female socket	01
MSS-004	4	Pan head cross crew M3x8	04
MSS-005	5	Battery Dislay	01
MSS-006	6	U bracket	01
MSS-007	7	Battery	01
MSS-008	8	Pan head cross crew M3x15	06
MSS-009	9	Battery bracket	01
MSS-010	10	Light	01
MSS-011	11	Main frame	01
MSS-012	12	Drive	01
MSS-013	13	Control circuit	02
MSS-014	14	Pan head cross crew M4x30	08
MSS-015	15	Socket head cap M8x80	04
MSS-016	16	Washer M8	04
MSS-017	17	Motor 24v	01
MSS-018	18	Bearing 51207	01
MSS-019	19	Socket head cap M6x50	04
MSS-020	20	Joint bearing	01
MSS-021	21	Brass washer	01
MSS-022	22	Key	01
MSS-023	23	Main shaft	01
MSS-024	24	Nylon nut M16	01
MSS-025	25	Hook shape H	01
MSS-026	26	Socket head cap M16x90	01
MSS-027	27	Washer Ø16	02
MSS-028	28	Coupling	01
MSS-029	29	Coupling pin	01
MSS-030	30	Cotter pin	01